

Rider's Manual

K 1300 R



BMW Motorrad



The Ultimate
Riding Machine

Motorcycle data/dealership details

Motorcycle data

Model

Vehicle identification number

Colour code

Date of first registration

Registration number

Dealership details

Person to contact in Service department

Ms/Mr

Phone number

Dealership address/phone number (company stamp)

Welcome to BMW

We congratulate you on your choice of a motorcycle from BMW and welcome you to the community of BMW riders.

Familiarise yourself with your new motorcycle so that you can ride it safely and confidently in all traffic situations.

Please read this Rider's Manual carefully before starting to use your new BMW motorcycle. It contains important information on how to operate the controls and how to make the best possible use of all your BMW's technical features.

In addition, it contains information on maintenance and care to help you maintain your motorcycle's reliability and safety, as well as its value.

If you have questions concerning your motorcycle, your authorised

BMW Motorrad dealer will gladly provide advice and assistance.

We hope that you will enjoy riding your BMW and that all your journeys will be pleasant and safe.

BMW Motorrad.

Table of Contents

You can also consult the index at the end of this Rider's Manual if you want to find a particular topic or item of information.

1 General instructions 5

Overview 6

Abbreviations and symbols 6

Equipment 7

Technical data 7

Currency 7

2 General views 9

General view, left side 11

General view, right side 13

Handlebar fitting, left 14

Handlebar fitting, right 15

Underneath the seat 16

Instrument cluster 17

Headlight 18

3 Status indicators 19

Standard status indicators 20

Status indicators with on-board computer 21

Status indicators with tyre pressure monitoring (RDC) 22

Status indicators with grip heating 22

Standard warnings 23

Warnings issued by the on-board computer 29

ABS warnings 31

ASC warnings 34

RDC warnings 36

Anti-theft alarm warnings... 41

4 Operation..... 45

Ignition switch and steering lock 46

Electronic immobiliser EWS 47

Clock 48

Odometer and tripmeters 49

On-board computer 51

Tyre pressure monitoring RDC..... 54

Lights 55

Turn indicators 55

Hazard warning flashers 56

Emergency off switch (kill switch) 57

BMW Motorrad Integral ABS 57

Automatic Stability Control ASC..... 58

Grip heating 59

Clutch 60

Brakes 60

Mirrors 61

Spring preload 62

Damping 62

Electronic Suspension Adjustment ESA 63

Tyres..... 65

Headlight 66

| | | | | | |
|------------------------------------|-----------|----------------------------|-----------|--------------------------------|------------|
| Seat | 66 | 7 Accessories | 91 | 9 Care | 131 |
| Luggage loops | 67 | General instructions | 92 | Care products | 132 |
| 5 Riding | 69 | Power socket | 92 | Washing motorcycle | 132 |
| Safety instructions | 70 | Luggage | 93 | Cleaning easily damaged | |
| Checklist | 71 | Case | 94 | components | 132 |
| Starting | 72 | 8 Maintenance | 99 | Paint care | 133 |
| Running in | 74 | General instructions | 100 | Protective wax coating | 134 |
| Shifting gear | 75 | Toolkit | 100 | Laying up motorcycle | 134 |
| Brakes | 76 | Engine oil | 101 | Restoring motorcycle to | |
| Parking your motorcycle | 77 | Brake system | 102 | use | 134 |
| Refuelling | 79 | Brake pads | 103 | 10 Technical data | 135 |
| Securing motorcycle for | | Brake fluid | 105 | Troubleshooting chart | 136 |
| transportation | 80 | Clutch | 106 | Threaded fasteners | 137 |
| 6 Engineering details | 83 | Tyres | 107 | Engine | 139 |
| Brake system with BMW | | Rims | 108 | Fuel | 140 |
| Motorrad Integral ABS | 84 | Wheels | 108 | Engine oil | 140 |
| Electronic engine manage- | | Front-wheel stand | 117 | Clutch | 141 |
| ment with BMW Motorrad | | Rear-wheel stand | 118 | Transmission | 141 |
| ASC | 86 | Bulbs | 119 | Rear-wheel drive | 142 |
| Tyre pressure monitoring | | Jump starting | 125 | Running gear | 142 |
| RDC | 88 | Battery | 126 | Brakes | 144 |
| Electronic Suspension Ad- | | | | Wheels and tyres | 144 |
| justment ESA II | 89 | | | Electrics | 145 |
| | | | | Frame | 147 |
| | | | | Dimensions | 147 |

| | |
|---|------------|
| Weights | 148 |
| Riding specifications | 148 |
| 11 Service | 149 |
| BMW Motorrad service.... | 150 |
| BMW Motorrad service quality | 150 |
| BMW Motorrad mobility services - roadside assist- ance..... | 150 |
| BMW Motorrad service network | 151 |
| Maintenance work..... | 151 |
| Confirmation of mainten- ance work | 152 |
| Confirmation of service.... | 157 |

General instructions

| | |
|---------------------------------|---|
| Overview | 6 |
| Abbreviations and symbols | 6 |
| Equipment | 7 |
| Technical data | 7 |
| Currency | 7 |

Overview

Chapter 2 of this Rider's Manual will provide you with an initial overview of your motorcycle. All maintenance and repair work on the motorcycle is documented in Chapter 11. This record of the maintenance work you have had performed on your motorcycle is a precondition for generous treatment of goodwill claims.

When the time comes to sell your BMW, please remember to hand over this Rider's Manual; it is an important part of the motorcycle.

Abbreviations and symbols



Indicates warnings that you must comply with for reasons of your safety and the safety of others, and to protect your motorcycle against damage.



Specific instructions on how to operate, control, adjust or look after items of equipment on the motorcycle.



Indicates the end of an item of information.



Instruction.



Result of an activity.



Reference to a page with more detailed information.



Indicates the end of a passage relating to specific accessories or items of equipment.



Tightening torque.



Item of technical data.

OE Optional extra
The motorcycles are assembled complete with all the BMW optional extras originally ordered.

OA Optional accessory
You can obtain optional accessories through your authorised BMW Motorrad dealer; optional accessories have to be retrofitted to the motorcycle.

EWS Electronic immobiliser.

DWA Anti-theft alarm (Diebstahlwarnanlage)

ABS Anti-lock brake system

ASC Automatic Stability Control.

ESA Electronic Suspension Adjustment
Electronic Suspension Adjustment.

RDC Tyre pressure control
(ReifenDruck-Control)

Equipment

When you ordered your BMW motorcycle, you chose various items of custom equipment. This Rider's Manual describes optional extras (OE) offered by BMW and selected optional accessories (OA). This explains why the manual may also contain descriptions of equipment which you have not ordered. Please note, too, that your motorcycle might not be exactly as illustrated in this manual on account of country-specific differences. If your BMW was supplied with equipment not described in this Rider's Manual, you will

find these features described in separate manuals.

Technical data

All dimensions, weights and power ratings stated in the Rider's Manual are quoted to the standards and comply with the tolerance requirements of the Deutsches Institut für Normung e.V. (DIN). Versions for individual countries may differ.


Currency

The high safety and quality standards of BMW motorcycles are maintained by constant development work on designs, equipment and accessories. Because of this, your motorcycle may differ from the information supplied in the Rider's Manual. Nor can BMW Motorrad entirely rule out errors and omissions. We hope you will appreciate that no claims can be entertained on

the basis of the data, illustrations or descriptions in this manual.


General views

| | |
|--------------------------------|----|
| General view, left side..... | 11 |
| General view, right side | 13 |
| Handlebar fitting, left | 14 |
| Handlebar fitting, right | 15 |
| Underneath the seat | 16 |
| Instrument cluster | 17 |
| Headlight | 18 |



General view, left side

- 1 Clutch-fluid reservoir
(⇒ 107)
- 2 Seat lock (underneath the rear light) (⇒ 66)
- 3 Adjuster for spring preload, rear (⇒ 62)
- 4 Adjuster for damping characteristic, rear suspension (⇒ 63)
- 5 Power socket (⇒ 92)



General view, right side

- 1 Engine oil level indicator
(⇒ 101)
- 2 Fuel filler neck (⇒ 79)
- 3 Battery compartment
(⇒ 127)
- 4 Brake-fluid reservoir, front
(⇒ 103)
- 5 Vehicle identification number (on side panel, front right)
- 6 Type plate (on rear cross-tube)
- 7 Brake-fluid reservoir, rear
(⇒ 106)

Handlebar fitting, left

- 1 High-beam headlight and headlight flasher (→ 55)
- 2 Operating the odometer (→ 49)
 - with on-board computer^{OE}
 - Operating the on-board computer (→ 51)
- 3 Hazard warning flashers (→ 56)
- 4 Operation of the flashing turn indicators (→ 55)
- 5 Horn
- 6 – with Electronic Suspension Adjustment (ESA II)^{OE}
 - Operating ESA (→ 63)
- 7 – with Automatic Stability Control^{SA}
 - Operating ASC (→ 58)
 - with BMW Motorrad Integral ABS II^{OE}
 - Operating the ABS (→ 57)







Handlebar fitting, right

- 1 – with heated handlebar grips^{SA}
Grip heating (→ 59)
- 2 Starter button (→ 72)
- 3 Emergency off switch (kill switch) (→ 57)

Underneath the seat

- 1 Luggage loops
- 2 Rider's Manual
- 3 Tyre pressure table and payload table
- 4 Standard toolkit (→ 100)
- 5 Engine-oil filler neck (→ 102)






Instrument cluster

- 1 Rev. counter
- 2 Speedometer
- 3 Telltale lights (→ 20)
- 4 Multifunction display (→ 20)
- 5 Ambient-light brightness sensor (for adapting the brightness of the instrument lighting)
 - with anti-theft alarm (DWA)^{OE}
 Anti-theft alarm telltale light (see the instructions for use for the anti-theft alarm)
- 6 Operating the odometer (→ 49)
Operation of the clock (→ 48)

▶ The instrument-cluster lighting has automatic day and night switchover. ◀

Headlight

- 1 Low-beam headlight
- 2 High-beam headlight
- 3 Side light




Status indicators

| | |
|--|----|
| Standard status indicators | 20 |
| Status indicators with on-board computer | 21 |
| Status indicators with tyre pressure monitoring (RDC) | 22 |
| Status indicators with grip heat- ing | 22 |
| Standard warnings | 23 |
| Warnings issued by the on-board computer | 29 |
| ABS warnings | 31 |
| ASC warnings | 34 |
| RDC warnings | 36 |
| Anti-theft alarm warnings | 41 |

Standard status indicators

Multifunction display



- 1 Gear indicator (⇒ 20)
- 2 Clock (⇒ 48)
- 3 Coolant temperature (⇒ 20)
- 4 Odometer and tripmeters (⇒ 49)
- 5 Fuel capacity (⇒ 20)

Telltale lights



- 1 Flashing turn indicators, left
- 2 High-beam headlight
- 3 Idle
- 4 Flashing turn indicators, right

Fuel capacity



The horizontal bars below the fuel-pump symbol indicate the remaining quantity of fuel.

When the fuel in the tank is topped up the gauge briefly

shows the original level, before the reading is updated.

Gear indicator

The gear engaged or **N** for neutral appears on the display.



If no gear is engaged, the 'neutral' telltale light also lights up.

Coolant temperature



The horizontal bars below the temperature symbol indicate the coolant temperature.

Service-due indicator



If the next service is due in less than one month, the date for the next service **1** is shown briefly after the Pre-Ride Check completes. Month and year are both shown as two-digit numbers with a colon as separator, so in this example the next service is due in March 2010.



If the motorcycle covers long distances in the course of the year, under certain circumstances it might be necessary to have it serviced at a date in advance of the forecast due date. If the countdown distance to the odometer reading at which a service will be due is less than 1000 km, the distance is counted down in steps of 100 km **2** and is shown briefly after the Pre-Ride Check completes.

If service is overdue, the due date or the odometer reading at which service was due is accom-

panied by the 'General' warning light showing yellow. The word "Service" remains permanently visible.

▶ If the service-due indicator appears more than a month before the service date, the date saved in the instrument cluster must be adjusted. This situation can occur if the battery was disconnected for a prolonged period of time.

If you want to have the date set consult a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

Status indicators with on-board computer

– with on-board computer^{OE}



- 1 Status-indicator panel of the on-board computer (→ 51)

Status indicators with tyre pressure monitoring (RDC)

- with tyre pressure monitoring (RDC)^{OE}



- 1 Tyre-pressure readout (→ 54)

▶ The figures shown in the tyre-pressure readings are temperature-compensated (see the section entitled "Engineering details").◀

Status indicators with grip heating

- with heated handlebar grips^{SA}




- 1 Display of the heating stages (→ 59)

Standard warnings

Mode of presentation

The possible warnings are listed on the next page.














Warnings are indicated by the 'General' warning light **1** showing in combination with a warning word, for example **2** or in combination with one of the warning symbols **3**. The 'General' warning light shows red or yellow, depending on the urgency of the warning. If two or more warnings occur at the same time, all the appropriate warning lights and warning symbols appear, alternating with warning words as applicable.

Warnings, overview

Telltale lights

Status indicators

Meaning

| | | | |
|--|------------------|---|--|
|  | Lights up yellow | EWS ! Appears on the display | Electronic immobiliser active (→ 26) |
|  | Lights up yellow | FUEL ! Appears on the display | Fuel down to reserve (→ 26) |
|  | Lights up red |  Temperature reading flashes | Coolant temperature too high (→ 26) |
|  | Lights up yellow |  Appears on the display | Engine in emergency-operation mode (→ 27) |
|  | Flashes red |  Appears on the display | Insufficient engine oil pressure (→ 27) |
|  | Lights up red |  Appears on the display | Insufficient battery charge current (→ 28) |
|  | Lights up yellow | LAMP R ! Appears on the display | Rear light bulb defective (→ 28) |
| | | LAMP F ! Appears on the display | Front light bulb defective (→ 28) |

Telltale lights

Status indicators

Meaning



Lights up yellow

LAMPS ! Appears
on the display

Bulbs defective (→ 29)

Electronic immobiliser active



General warning light shows yellow.

EWS ! appears on the display.

Possible cause:

The key being used is not authorised for starting, or communication between key and engine electronics is disrupted.

- Remove all other vehicle keys from the same ring as the ignition key.
- Use the reserve key.
- Have the defective key replaced, preferably by an authorised BMW Motorrad dealer.

Fuel down to reserve



General warning light shows yellow.

FUEL ! appears on the display.




Lack of fuel can result in the engine misfiring and cutting out unexpectedly. Misfiring can damage the catalytic converter; a hazardous situation can result if the engine cuts out unexpectedly.

Do not run the fuel tank dry.◀

Possible cause:

The fuel tank contains no more than the reserve quantity of fuel.



- Refuelling (→ 79).

Coolant temperature too high



General warning light shows red.



The temperature reading flashes.



Continuing to ride when the engine is overheated could result in engine damage.

You must comply with the instructions below.◀

Possible cause:

The coolant temperature is too high.

- If possible, ride in the part-load range to cool down the engine.
- In traffic jams, switch off the engine, but leave the ignition switched on so that the radiator or fan continues to operate.
- If the coolant temperature is frequently too high, have the fault rectified as soon as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Engine in emergency-operation mode



General warning light shows yellow.



Engine symbol appears on the display.



The engine is running in emergency operating mode.

Engine power might be reduced and this can cause hazardous situations, particularly if you attempt to overtake other road users.

Engine power level might be lower than normal: adapt your style of riding accordingly.◀

Possible cause:

The engine control unit has diagnosed a fault. In exceptional cases, the engine stops and refuses to start. Otherwise, the engine runs in emergency operating mode.

- You can continue to ride, but bear in mind that the usual engine power might not be available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Insufficient engine oil pressure




General warning light flashes red.



Oil-can symbol appears on the display.

The oil pressure in the lube-oil system is too low. Stop immediately and switch off the engine if the warning light shows.

 The insufficient oil pressure warning does not fulfil the function of an oil gauge. The only way of checking whether the

oil level is correct is to check the oil level indicator.◀

Possible cause:

The engine-oil level is too low.

- Check the engine oil level (⇒ 101).

If the oil level is too low:

- Top up the engine oil (⇒ 102).

Possible cause:

The engine-oil pressure is insufficient.



Riding when engine-oil pressure is low can result in engine damage.

Do not continue your journey.◀

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Insufficient battery charge current



General warning light shows red.



Battery symbol appears on the display.



A discharged battery can render various systems unavailable, for example the lights, the engine or the ABS. This can result in dangerous situations. If possible, do not continue your journey. ◀

Battery is not being charged. If you continue to ride the motorcycle the on-board electronics will drain the battery.

Possible cause:

Alternator or alternator drive belt defective

- Have the fault rectified as quickly as possible by a specialist workshop, preferably

an authorised BMW Motorrad dealer.

Rear light bulb defective



General warning light shows yellow.

LAMPR ! appears on the display.



A defective bulb places your safety at risk because it is easier for other users to oversee the motorcycle.

Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible. ◀

Possible cause:

Rear light or brake light bulb defective.

- The LED rear light must be replaced. Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.

Front light bulb defective

LAMPF ! appears on the display.



A defective bulb places your safety at risk because it is easier for other users to oversee the motorcycle.

Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible. ◀

Possible cause:

Low-beam headlight, high-beam headlight, side light or turn indicator bulb defective.

- Replacing low-beam and high-beam headlight bulb (➡ 120).
- Replacing parking-light bulb (➡ 121).
- Replacing turn indicator bulbs, front and rear (➡ 123).

Bulbs defective



General warning light shows yellow.

LAMPS ! appears on the display.



A defective bulb places your safety at risk because it is easier for other users to oversee the motorcycle. Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible. ◀

Possible cause:

A combination of the bulb defects described above has occurred.

- See the fault descriptions above.

Warnings issued by the on-board computer

– with on-board computer^{OE}

Mode of presentation



Warnings issued by the on-board computer appear as one of the symbols **1**.

The possible warnings are listed on the next page.

Warnings, overview

Telltale lights

Status indicators

Meaning



Appears on the display

Engine-oil level too low (➔ 31)

Check Oil
Appears on the display



Appears on the display

Ice warning (➔ 31)

Engine-oil level too low



Oil-level symbol appears on the display.

Check Oil appears on the display.

Possible cause:

The electronic oil-level sensor has registered an excessively low oil level. Check the engine-oil level at the oil-level indicator the next time you stop to refuel:

- Check the engine oil level (➔ 101).

If the oil level is too low:

- Top up the engine oil (➔ 102).

Possible cause:

The oil sensor might be defective if the "Check oil level" message appears even though a check of the oil sight glass shows that the oil level is correct.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Ice warning



Ice-crystal symbol appears on the display.

Possible cause:

The air temperature measured at the motorcycle is lower than 3 °C.



The ice warning does not mean that there is no risk of black ice forming at measured temperatures above 3 °C.

Always take extra care and think well ahead when temperatures are low; remember that the danger of black ice is particularly high on bridges and where the road is in the shade.◀

- Ride carefully and think well ahead.

ABS warnings

– with BMW Motorrad Integral ABS II^{OE}

Mode of presentation



ABS warnings are indicated by ABS warning light **1**.

The way in which the ABS warning light indicates status can differ in some countries.



Possible national variant.




The detailed descriptions relating to BMW Motorrad Integral ABS start on page (➔ 84), and you will find an overview listing the possible warnings on the next page.

Warnings, overview

Telltale lights

Status indicators

Meaning

| | | |
|--|-----------|--|
|  | Flashes | ABS self-diagnosis not completed (➡ 34) |
|  | Lights up | ABS deactivated (➡ 34) |
|  | Lights up | ABS fault (➡ 34) |

ABS self-diagnosis not completed



ABS warning light flashes.

Possible cause:

The ABS function is not available, because self-diagnosis did not complete. The motorcycle has to move forward a few metres for the wheel sensors to be tested.

- Pull away slowly. Bear in mind that the ABS function is not available until self-diagnosis has completed.

ABS deactivated



ABS warning light shows.

Possible cause:

The rider has switched off the ABS system.

– with BMW Motorrad Integral ABS II^{OE}

- Activate the ABS function (→ 58).

ABS fault



ABS warning light shows.

Possible cause:

The ABS control unit has detected a fault. The ABS function is not available.

- You can continue to ride the motorcycle, but make due provision for the fact that the ABS function is not available. Bear in mind the more detailed information on situations that can lead to an ABS fault (→ 85).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ASC warnings

– with Automatic Stability Control^{SA}

Mode of presentation









ASC warnings are indicated by a combination of the ASC warning symbol **2** and 'General' warning light **1**.

The detailed descriptions relating to BMW Motorrad ASC start on page (→ 86), and you will find an overview listing the possible warnings on the next page.

Warnings, overview

Telltale lights

| | Status indicators | Meaning |
|---|--|-------------------------------------|
|  Quick-flashes yellow |  Appears on the display | ASC intervention (→ 36) |
| |  Slow-flashes | Self-diagnosis not completed (→ 36) |
| |  Appears on the display | ASC deactivated (→ 36) |
|  Lights up yellow |  Appears on the display | ASC fault (→ 36) |

ASC intervention



General warning light quick-flashes yellow.



ASC symbol appears on the display.

The ASC has detected a degree of instability at the rear wheel and has intervened to reduce torque. The warning light flashes for longer than ASC intervention lasts. This affords the rider visual feedback on control intervention even after the critical situation has been dealt with.

Self-diagnosis not completed



ASC symbol flashes.

Possible cause:

Self-diagnosis did not complete, so the ASC function is not available. The engine must be running and the motorcycle must

reach a speed of at least 5 km/h in order for ASC self-diagnosis to complete.

- Pull away slowly. Bear in mind that the ASC function is not available until self-diagnosis has completed.

ASC deactivated



ASC symbol appears on the display.

Possible cause:

The rider has switched off the ASC system.

- with Automatic Stability Control^{SA}
- Activate the ASC function (⇒ 59).

ASC fault



General warning light shows yellow.



ASC symbol appears on the display.

Possible cause:

The ASC control unit has detected a fault. The ASC function is not available.


- You can continue to ride. Bear in mind that the ASC function is not available. Bear in mind the more detailed information on situations that can lead to an ASC fault (⇒ 87).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

RDC warnings

– with tyre pressure monitoring (RDC)^{OE}

Mode of presentation

The tyre-pressure readings are based on a reference tyre temperature of 20 °C (⇒ 89).



an overview listing the possible warnings on the next page.

Warning symbol **2** indicates a critical tyre pressure, and the corresponding reading for the front tyre pressure **3** or the rear tyre pressure **4** flashes.

If the critical value is close to the limit of the permissible tolerance range, 'General' warning light **1** shows yellow. If the tyre pressure registered by the sensor is outside the permissible tolerance range, the general warning light **1** flashes red.








The detailed descriptions relating to BMW Motorrad RDC start on page (➔ 88), and you will find

Warnings, overview

Telltale lights

Status indicators

Meaning

| | | | |
|--|------------------|---|--|
|  | Lights up yellow |  | Tyre pressure close to limit of permitted tolerance (➔ 39) |
| | | The critical tyre pressure flashes. | |
|  | Flashes red |  | Tyre pressure outside permitted tolerance (➔ 39) |
| | | The critical tyre pressure flashes. | |
| | | "--" or "-- --" is displayed. | Signal transmission disrupted (➔ 39) |
|  | Lights up yellow |  | Sensor defective or system error (➔ 40) |
| | | "--" or "-- --" is displayed. | |
|  | Lights up yellow | RDC ! appears on the display | Battery of tyre-pressure sensor weak (➔ 41) |

Tyre pressure close to limit of permitted tolerance



General warning light shows yellow.



Tyre symbol appears on the display.

The critical tyre pressure flashes.
Possible cause:

Measured tyre pressure is close to the limit of permitted tolerance.

- Correct the tyre pressure as stated on the inside cover of the Rider's Manual.



Before you adjust tyre pressure, read the information on temperature compensation and adjusting pressure in the section entitled "Engineering details".◀

Tyre pressure outside permitted tolerance



General warning light flashes red.



Tyre symbol appears on the display.

The critical tyre pressure flashes.
Possible cause:

Measured tyre pressure is outside permitted tolerance.

- Check the tyre for damage and to ascertain whether the motorcycle can be ridden with the tyre in its present condition.

If the motorcycle can be ridden with the tyre in its present condition:



Incorrect tyre pressures impair the motorcycle's handling characteristics.

If tyre pressure is incorrect it is essential to adapt your style of riding accordingly.◀

- Correct the tyre pressure at the earliest possible opportunity.



Before you adjust tyre pressure, read the information on temperature compensation and adjusting pressure in the section entitled "Engineering details".◀

- Have the tyre checked for damage by a specialist workshop, preferably an authorised BMW Motorrad dealer.

If you are unsure whether the motorcycle can be ridden with the tyre in its present condition:

- Do not continue your journey.
- Notify the breakdown service.

Signal transmission disrupted

"--" or "-- --" is displayed.

Possible cause:

The motorcycle has not yet accelerated past the threshold of approximately 30 km/h. The RDC sensors do not start transmitting signals until the motorcycle reaches a speed above this threshold for the first time (➔ 88).

- Increase speed above this threshold and observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany the symptoms. Under these circumstances:
- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Possible cause:

Wireless communication with the RDC sensors has been disrupted. Possible causes include radio-communication systems operating in the vicinity and interfering with the link between the RDC control unit and the sensors.

- Move to another location and observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany the symptoms. Under these circumstances:
- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Sensor defective or system error



General warning light shows yellow.



Tyre symbol appears on the display.

"_ _" or "_ _ _ _" is displayed.

Possible cause:

Motorcycle is fitted with wheels not equipped with RDC sensors.

- Fit wheels and tyres equipped with RDC sensors.

Possible cause:

One or two RDC sensors have failed.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Possible cause:

A system error has occurred.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Battery of tyre-pressure sensor weak



General warning light shows yellow.

RDC ! appears on the display.



This error message appears only briefly after the pre-ride check completes. ◀

Possible cause:


The integral battery in the tyre-pressure sensor has lost a significant proportion of its original capacity. There is no assurance of how long the tyre pressure control system can remain operational.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Anti-theft alarm warnings

– with anti-theft alarm (DWA)^{OE}

Mode of presentation



Anti-theft alarm warnings appear as plain-text warnings **2** in combination with the 'General' warning light **1** showing after the Pre-Ride Check and relate to the capacity of the internal battery that supplies power to the anti-theft alarm.

The possible warnings are listed on the next page.

Warnings, overview**Telltale lights****Status indicators****Meaning**

DWALO ! Appears
on the display

Anti-theft alarm battery weak (➡ 43)




Lights up yellow

DWA ! Appears on
the display

Anti-theft alarm battery flat (➡ 43)

Anti-theft alarm battery weak

DWALO ! appears on the display.


 This error message appears only briefly after the pre-ride check completes.◀

Possible cause:


The integral battery in the anti-theft alarm has lost a significant proportion of its original capacity. There is no assurance of how long the anti-theft alarm can remain operational if the motorcycle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Anti-theft alarm battery flat

 General warning light shows yellow.

DWA ! appears on the display.

 This error message appears only briefly after the pre-ride check completes.◀

Possible cause:

The integral battery in the anti-theft alarm has lost its entire original capacity. There is no assurance that the anti-theft alarm will be operational if the motorcycle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Operation

| | | | |
|--|----|---|----|
| Ignition switch and steering lock | 46 | Brakes | 60 |
| Electronic immobiliser EWS..... | 47 | Mirrors | 61 |
| Clock | 48 | Spring preload | 62 |
| Odometer and tripmeters | 49 | Damping | 62 |
| On-board computer | 51 | Electronic Suspension Adjustment ESA | 63 |
| Tyre pressure monitoring RDC | 54 | Tyres | 65 |
| Lights..... | 55 | Headlight | 66 |
| Turn indicators..... | 55 | Seat | 66 |
| Hazard warning flashers..... | 56 | Luggage loops | 67 |
| Emergency off switch (kill switch)..... | 57 | | |
| BMW Motorrad Integral ABS | 57 | | |
| Automatic Stability Control ASC | 58 | | |
| Grip heating..... | 59 | | |
| Clutch | 60 | | |

Ignition switch and steering lock

Keys

You receive two master keys and one spare key. Please consult the information on the electronic immobiliser (EWS) if a key is lost or mislaid (⇒ 47).

Ignition switch and steering lock, tank filler cap lock and seat lock are all operated with the same key.

– with case^{OA}

If you wish you can arrange to have the cases fitted with locks that can be opened with this key as well. Consult a specialist workshop, preferably an authorised BMW Motorrad dealer.<

Switching on ignition



- Turn the key to position **1**.
 - » Side light and all function circuits switched on.
 - » Engine can be started.
 - » Pre-ride check is performed. (⇒ 73)
- with BMW Motorrad Integral ABS II^{OE}
 - » ABS self-diagnosis is performed. (⇒ 73)
- with Automatic Stability Control^{SA}
 - » ASC self-diagnosis is performed. (⇒ 74)


Switch off the ignition



- Turn the key to position **2**.
 - » Lights switched off.
 - » Handlebars not locked.
 - » Key can be removed.
 - » Electrically powered accessories remain operational for a limited period of time.
 - » The battery can be recharged via the on-board socket.

Locking handlebars



 If the motorcycle is on the side stand, the surface of the ground will determine whether it is better to turn the handlebars to the left or right. However, the motorcycle is more stable on a level surface with the handlebars turned to the left than with the handlebars turned to the right.

On level ground, always turn the handlebars to the left to set the steering lock. ◀

- Turn the handlebars to the full left or right lock position.

- Turn the key to position **3**, while moving the handlebars slightly.
 - » Ignition, lights and all function circuits switched off.
 - » Handlebars locked.
 - » Key can be removed.

Electronic immobiliser EWS


Protection against theft

The electronic immobiliser helps protect your BMW motorcycle from theft, and this enhanced security is at your disposal without any need for you to set parameters or activate additional systems. The engine of a motorcycle fitted with this electronic immobiliser can be started only with the keys that belong to the vehicle. You can also have your authorised BMW Motorrad dealer bar individual keys, for example if a particular key goes missing. The

engine cannot be started with a key that has been barred.

In-key electronics

The motorcycle's electronics exchange certain continuously changing signals with the electronics in the key; these signals are specific to your motorcycle and they are transmitted via the ring aerial in the ignition lock. The ignition is not enabled for starting until the engine control unit has recognised the key as "authorised" for your motorcycle.

 A spare key attached to the same ring as the ignition key used to start the engine could "irritate" the electronics, in which case the enabling signal for starting is not issued. The EWS warning appears in the multifunction display. Always keep the spare key separately from the ignition key. ◀

Replacement and extra keys

You can obtain replacement/extra keys only through an authorised BMW Motorrad dealer. The keys are part of an integrated security system, so the dealer is under an obligation to check the legitimacy of all applications for replacement/extra keys. If you want to have a lost key barred, you have to bring with you all the other keys that belong to the motorcycle. A key that has been barred can subsequently be cleared and reactivated for use.

Clock

Setting clock



Attempting to set the clock while riding the motorcycle can lead to accidents.

Set the clock only when the motorcycle is stationary. ◀

- Switch on the ignition.
- without on-board computer^{OE}
- without tyre pressure monitoring (RDC)^{OE}




- Repeatedly press button **1** or button **2** until the odometer reading appears on the display. ◀

- with on-board computer^{OE}
- or
- with tyre pressure monitoring (RDC)^{OE}



- Repeatedly press button **2** until the clock appears on the display. ◀



- Press and hold down the button until the hours number **3** flashes.
- Repeatedly press the button until the hours number is correct.
- Press and hold down the button until the minutes number **4** flashes.
- Repeatedly press the button until the minutes number is correct.
- Hold down the button until the minutes number stops flashing.
- » This completes the process.

Odometer and tripmeters


Selecting readings

- Switch on the ignition.
 - without on-board computer^{OE}
 - without tyre pressure monitoring (RDC)^{OE}



- Press button **1** or button **2**.<

- with on-board computer^{OE}
- or
- with tyre pressure monitoring (RDC)^{OE}



- Press button **1**.<



- Repeatedly press the button until the value you want appears in panel **3**.

The following values can be displayed:

- Total distance covered
- Tripmeter 1 (Trip I)
- Tripmeter 2 (Trip II)
- without on-board computer^{OE}

Residual range (once fuel level is down to reserve)

Resetting tripmeter


- Switch on the ignition.
- Select the desired tripmeter.

- without on-board computer^{OE}
- without tyre pressure monitoring (RDC)^{OE}



- Press and hold down button **1** or button **2** until the tripmeter reading is reset.<

- with on-board computer^{OE} or
- with tyre pressure monitoring (RDC)^{OE}



- Press and hold down button **1** until the tripmeter reading is reset.<

Residual range

- without on-board computer^{OE}



The residual-range readout **1** indicates how far you can ride with the fuel remaining in the tank. This reading is not displayed until fuel level has dropped to reserve. This distance is calculated on the basis of fuel level and average consumption.

When refuelling after running on reserve, make sure that you top up the tank to a level above reserve, as otherwise the sensor will not be able to register the new level. If the sensor cannot register the new level the residual-range readout cannot be updated.

▶ The calculated range is an approximate value. Consequently, BMW Motorrad recommends that you should not try to use the full residual range before refuelling.◀

On-board computer


– with on-board computer^{OE}

Selecting readings

- Switch on the ignition.



- Press button **1**.



The following values can be displayed in panel **2**:

- Clock (CLOCK)
- Ambient temperature (TEMP)
- Average speed (ØSPEED)
- Average fuel consumption (ØFUEL)
- Range (RANGE)
- Oil-level reminder (OIL)
- with tyre pressure monitoring (RDC)^{OE}
- Tyre pressures (RDC P)

Ambient temperature



When the motorcycle is at a standstill the heat of the engine can falsify ambient-temperature reading **1**. If the effect of the engine's heat becomes excessive, -- temporarily appears on the display.



If ambient temperature drops below 3 °C a warning appears, drawing your attention to the risk of black ice forming. The display automatically switches from any other mode to the temperature reading when

the temperature drops below this threshold for the first time.

Average speed



Average speed **1** is calculated on the basis of the time elapsed since the last reset. Times during which the engine was stopped are excluded from the calculation.

Resetting average speed

- Switch on the ignition.
- Select average speed.



- Press and hold down button **1**.
- » Average speed is reset to zero.

Average consumption



Average consumption **1** is calculated by dividing the distance covered since the last reset by

the corresponding amount of fuel used.

Resetting average consumption

- Switch on the ignition.
- Select average speed.



- Press and hold down button **1**.
» Average consumption is reset to zero.

Range



The description of the residual-range function (→ 50) also covers range readout **1**. You can also view the range before the fuel level drops to reserve.

A special average-consumption figure is used to calculate range; this figure is not necessarily the same as the value you can call up for viewing on the display.

When the motorcycle is propped on its side stand the slight angle of inclination means that the sensor cannot register the fuel level correctly. This is the reason why the range is calculated only

when the motorcycle is on the move.

▶ The calculated range is only an approximate reading. Consequently, BMW Motorrad recommends that you should not try to use the full range before refuelling.◀

Oil level



Oil-level indicator **1** gives you an indication of the engine oil level. You can call up this reading only when the motorcycle is at a standstill.

The preconditions for the oil level check are as follows:

- Engine at operating temperature.
- Engine idling for at least ten seconds.
- Side stand retracted.
- Make sure the motorcycle is upright.

The readings mean:

OK: Oil level is correct.

CHECK: Check the oil level the next time you stop for fuel.

---: Oil level cannot be measured (conditions as stated above not satisfied).



If you call up another reading on the on-board computer, this symbol remains visible until the sensor again registers a correct oil level.

The most recently measured level is displayed for five seconds when you next switch on the ignition.



The oil sensor might be defective if the "Check oil level" message reappears even though the oil level shown by the oil tank's level indicator is correct. In this case, consult your authorised BMW Motorrad dealer. ◀

Tyre pressure monitoring RDC

- with tyre pressure monitoring (RDC)^{OE}

Viewing tyre-pressure readings

- Switch on the ignition.



- Repeatedly press button **1** until the tyre-pressure readings appear on the display.



Tyre-pressure readings **2** are based on a reference tyre temperature of 20 °C. The front tyre pressure is on the left; the read-

ing on the right is the rear tyre pressure. --- --- appears directly after the ignition is switched on, because the sensors do not transmit tyre pressures until the first time the motorcycle accelerates to more than 30 km/h.

Lights

Side light

The side lights switch on automatically when the ignition is switched on.

▷ The side lights place a strain on the battery. Do not switch the ignition on for longer than absolutely necessary.◀

Low-beam headlight

The low-beam headlight switches on automatically when you start the engine.

▷ When the engine is not running you can switch on the lights by switching on the ignition and either switching on the high-beam headlight or operating the headlight flasher.◀

High-beam headlight and headlight flasher



- Push switch **1** forward to switch on the high-beam headlight.
- Pull switch **1** back to operate the headlight flasher.

Parking light

- Switch off the ignition.



- Immediately after switching off the ignition, press turn-indicator button **1** to the left and hold down.
 - » Parking light switches on.

Turn indicators

Operating flashing turn indicators

- Switch on the ignition.

▶ The turn indicators are cancelled automatically after you have ridden for approximately 10 seconds, or covered a distance of about 200 m.◀



- Push button **1** to the left to switch on the left flashing turn indicators.
- Push button **1** to the right to switch on the right flashing turn indicators.
- Centre button **1** to cancel the flashing turn indicators.

Hazard warning flashers

Switching on hazard warning flashers

- Switch on the ignition.

▶ The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary.◀

▶ If you press a turn-indicator button with the ignition switched on, the turn-indicator function is activated instead of the hazard warning flashers, and remains active until you release the button. The hazard warning flashers recommence flashing as soon as the button is released.◀




- Press button **1** to switch on the hazard warning flashers.
- » Ignition can be switched off.
- Press button **1** again to switch off the hazard warning flashers.

Emergency off switch (kill switch)



- 1** Emergency off switch (kill switch)

 Operating the kill switch when riding can cause the rear wheel to lock and thus cause a fall.

Do not operate the kill switch when riding. ◀

The emergency off switch is a kill switch for switching off the engine quickly and easily.



- a** Engine switched off
b Normal operating position (run)

BMW Motorrad Integral ABS

- with BMW Motorrad Integral ABS II^{OE}

Deactivating ABS function

- Bring the motorcycle to a stop or, if the motorcycle is at a standstill, switch on the ignition.




- Press and hold down button **1** until the ABS warning light changes status.



- ABS warning light shows.

- with Automatic Stability Control^{SA}
- » Initially, the ASC symbol changes status. Press and hold down button **1** until the ABS warning light responds. Under these circumstances there is no change in the ASC setting.
- Release button **1** within two seconds.


 ABS warning light remains ON.

» The ABS function is deactivated, but the integral function remains active.


Activating ABS function



• Press and hold down button **1** until the ABS warning light changes status.


 ABS warning light goes out; if self-diagnosis has not completed it starts flashing.

• Release button **1** within two seconds.

 The ABS warning light remains off or continues to flash.

» The ABS function is activated.

• You also have the option of switching the ignition off and then on again.


 If you switch the ignition off then on again and the ABS light comes back on, there is a fault in the ABS.◀

Automatic Stability Control ASC

– with Automatic Stability Control^{SA}


Deactivating ASC function

• Switch on the ignition.


 You have the option of deactivating the ASC function while the motorcycle is on the move.◀



• Press and hold down button **1** until the ASC symbol changes status.

 ASC symbol appears on the display.

• Release button **1** within two seconds.


 ASC symbol continues to show.

» The ASC function is deactivated.


Activating ASC function



- Press and hold down button **1** until the ASC symbol changes status.


 ASC symbol no longer shows; if self-diagnosis has not completed the ASC warning light starts flashing.

- Release button **1** within two seconds.

 ASC symbol still does not show or continues to flash.

» The ASC function is activated.

- You also have the option of switching the ignition off and then on again.


 An ASC fault has occurred if the ASC warning light shows when the motorcycle accelerates to a speed in excess of 10 km/h after the ignition was switched off and then on again.◀


Grip heating

– with heated handlebar grips^{SA}

Operating grip heating

- Start the engine.

 Grip heating can be activated only when the engine is running. If the engine is switched off, grip heating must be reactivated once the engine is switched on again.◀

 The increase in power consumption caused by the grip heating can drain the battery if you are riding at low en-


gine speeds. If the charge level is low, grip heating is switched off to ensure the battery's starting capability.◀




- Repeatedly press button **1** until the desired heating stage appears on the display.



The handlebar grips have two-stage heating. Stage two **2** is for heating the grips quickly: it is advisable to switch back to stage one as soon as the grips are warm.



50 % heating power





100 % heating power

» The selected heating stage will be saved if you allow a certain length of time to pass without making further changes.

Clutch

Adjusting clutch lever

 If the position of the clutch fluid reservoir is changed, air can enter the clutch system. Do not twist the handlebar fitting or the handlebars. ◀


 Attempting to adjust the clutch lever while riding the motorcycle can lead to accidents. Do not attempt to adjust the clutch lever unless the motorcycle is at a standstill. ◀



• Turn adjusting screw **1** clockwise to increase the span


between the clutch lever and the handlebar grip.

- Turn adjusting screw **1** counter-clockwise to reduce the span between the clutch lever and the handlebar grip.


 The adjusting screw is easier to turn if you push the clutch lever forward. ◀

Brakes

Adjusting handbrake lever

 Changing the position of the brake-fluid reservoir can allow air to penetrate the brake system.

Do not twist the handlebar fitting or the handlebars. ◀

 Attempting to adjust the handbrake lever while riding the motorcycle can lead to accidents.

Do not attempt to adjust the handbrake lever unless the motorcycle is at a standstill. ◀




Mirrors

Adjusting mirrors



- Turn adjusting screw **1** clockwise to increase the span between the brake lever and the handlebar grip.
- Turn adjusting screw **1** counter-clockwise to reduce the span between the brake lever and the handlebar grip.

 The adjusting screw is easier to turn if you push the handbrake lever forward. ◀

- Turn the mirror to the correct position.

Adjusting mirror arm



- Push protective cap **1** up over the threaded fastener on the mirror arm.
- Slacken nut **2** (left-hand thread).
- Turn the mirror arm to the appropriate position.
- Tighten nut to the specified tightening torque, while holding the mirror arm to ensure that it does not move out of position.



Mirror on left/right adapter

– 22 Nm

- Push the protective cap over the threaded fastener.

Spring preload


Setting


It is essential to set spring preload of the rear suspension to suit the load carried by the motorcycle. Increase spring preload when the motorcycle is heavily loaded and reduce spring preload accordingly when the motorcycle is lightly loaded.

Adjust the spring preload for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.



 Your motorcycle's handling will suffer if you do not match the spring-preload and damping-characteristic settings. Adjust the damping characteristic to suit spring preload.◀

 Adjusting spring preload while the motorcycle is being ridden can lead to accidents. Do not attempt to adjust spring preload unless the motorcycle is at a standstill.◀

- If you want to increase spring preload, turn knob **1** in the direction indicated by the HIGH arrow.

- If you want to reduce spring preload, turn knob **1** in the direction indicated by the LOW arrow.



Basic setting of spring preload, rear

– without Electronic Suspension Adjustment (ESA II)^{OE}

– Turn the knob as far as it will go in the direction indicated by the LOW arrow and then turn it back 13 clicks in the direction indicated by the HIGH arrow. (Full load of fuel, with rider 85 kg)◀

Damping

Setting

Damping must be adapted to suit the surface on which the motorcycle is ridden and to suit spring preload.

- An uneven surface requires softer damping than a smooth surface.
- An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.


Adjust the damping for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.




- Adjust the damping characteristic, using the tool from the


on-board toolkit to turn adjusting screw **1**.



- If you want a harder damping characteristic, turn adjusting screw **1** in the direction indicated by the H arrow.
- If you want a softer damping characteristic, turn adjusting screw **1** in the direction indicated by the S arrow.

 Basic setting of rear-suspension damping characteristic

- without Electronic Suspension Adjustment (ESA II)^{OE}

 Basic setting of rear-suspension damping characteristic

- Turn the adjusting screw as far as it will go in the direction indicated by the H arrow and then turn it back one and a half turns in the direction indicated by the S arrow. (Full load of fuel, with rider 85 kg)◀

Electronic Suspension Adjustment ESA

- with Electronic Suspension Adjustment (ESA II)^{OE}

Settings

Electronic Suspension Adjustment ESA provides a convenient way of adapting the motorcycle to the load it carries and the surface over which you intend riding. In order for this to happen, the

load status must be set and the desired riding mode selected.

Three load statuses can be set, with any of the three riding modes available for each one. The detailed description of the ESA II Electronic Suspension Adjustment system is on page (➔ 89).

Calling up settings

- Switch on the ignition.



- Press button **1** to view the current setting.



The selected riding mode is displayed in panel **1** of the multifunction display and the load status is displayed in panel **2**.

» The setting shows briefly, then disappears automatically.

Setting riding mode

- Start the engine.

▶ The riding mode can be set while the motorcycle is in motion.◀



- Press button **1** to view the current setting.
- Repeatedly press button **1** until the setting you want to use appears on the display.


The display field starts at the current status and cycles through the following sequence:

- COMF: comfort mode
- NORM: normal mode
- SPORT: sport mode
- » The riding mode shown on the display is accepted if you allow a certain length of time to pass without pressing button **1**; the

ESA setting then automatically disappears from the display.

Setting load status



- Start the engine.

 The load status cannot be set while the motorcycle is in motion.◀



- Press button **1** to view the current setting.
- Repeatedly press button **1** until the setting you want to use appears on the display.


The display field starts at the current status and cycles through the following sequence:




» The settings shown on the display are automatically accepted as the load status and, if applicable, the riding mode if you allow a certain length of time to pass without pressing button **1**. The ESA setting then automatically disappears from the display.

Tyres

Checking tyre pressure


 Incorrect tyre pressures impair the motorcycle's handling characteristics and increase the rate of tyre wear.

Always check that the tyre pressures are correct.◀


 At high road speeds, tyre valves installed perpendicular to the wheel rim have a tendency to open as a result of centrifugal force.

In order to avoid a sudden loss of tyre pressure, fit a valve cap with rubber sealing ring to the rear tyre and make sure that the cap is screwed on firmly.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Check tyre pressures against the data below.

 Tyre pressure, front

- 2.5 bar (Tyre cold)

 Tyre pressure, rear

- 2.9 bar (Tyre cold)

If tyre pressure is too low:

- Correct tyre pressure.

Headlight

Adjusting headlight for driving on left/driving on right

If the motorcycle is ridden in a country where the opposite rule of the road applies, its asymmetric low-beam headlight will tend to dazzle oncoming traffic.

Have the headlight set accordingly by a specialist workshop, preferably an authorised BMW Motorrad dealer.



Commercially available adhesive tape will damage the plastic lens of the light.

Consult a specialist workshop, preferably an authorised BMW Motorrad dealer, in order to avoid damaging the plastic lens of the light. ◀

Headlight beam throw and spring preload

Headlight beam throw is kept constant when spring preload is adjusted to suit load.



Consult a specialist workshop, preferably an authorised BMW Motorrad dealer, if you are unsure whether the headlight basic setting is correct. ◀

Seat

Remove the seat

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Turn the key to the left in seat lock **1** while supporting the seat at the back and pushing it down.



- Lift the seat at the rear and release the key.

- Remove the seat and place it, upholstered side down, on a clean surface.

Installing seat




- Engage the seat in holders **1**.
- Firmly press down on the seat at the rear.
- » The seat engages with an audible click.

Luggage loops


Securing luggage to motorcycle

- Remove the seat (⇒ 66).

- Turn the seat upside down.



- Pull the loops **1** out of the holders **2** and lay them on the outside.
- Install the seat (⇒ 67).



- Use the loops **1** and the grab handles **3** to attach luggage straps in order to lash luggage onto the rear seat.

Riding

| | |
|--|----|
| Safety instructions | 70 |
| Checklist | 71 |
| Starting | 72 |
| Running in | 74 |
| Shifting gear | 75 |
| Brakes | 76 |
| Parking your motorcycle | 77 |
| Refuelling | 79 |
| Securing motorcycle for transportation | 80 |

Safety instructions

Rider's equipment

Do not ride without the correct clothing. Always wear:

- Helmet
- Motorcycling jacket and trousers
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorised BMW Motorrad dealer will be glad to advise you on the correct clothing for every purpose.

Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle:

- Settings of the spring-strut and shock-absorber system
- Imbalanced load
- Loose clothing
- Insufficient tyre pressure
- Poor tyre tread
- Etc.

Correct loading



Overloading and imbalanced loads can adversely affect the motorcycle's handling. Do not exceed the permissible gross weight and be sure to comply with the instructions on loading.◀

Alcohol and drugs



Even small amounts of alcohol or drugs will adversely affect your perception and your ability to assess situations and make decisions, and slow down your reflexes. Medication can exacerbate these effects.

Do not ride your motorcycle after consuming alcohol, drugs and/or medication.◀

Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colourless and odourless but highly toxic.



Inhaling the exhaust fumes therefore represents a health hazard and can even cause loss of consciousness with fatal consequences.

Do not inhale exhaust fumes. Do not run the engine in an enclosed space.◀

High voltage



Touching live parts of the ignition system with the engine running can cause electric shock.


Do not touch parts of the ignition system when the engine is running.◀

Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.


For this reason, observe the following points:

- Do not run the fuel tank dry.
- Do not attempt to start or run the engine with a spark-plug cap disconnected.
- Stop the engine immediately if it misfires.
- Use only unleaded fuel.
- Comply with all specified maintenance intervals.


 Unburned fuel will destroy the catalytic converter. Note the points listed for protection of the catalytic converter. ◀

Risk of fire


Temperatures at the exhaust are high.

 Flammable materials (e.g. hay, leaves, grass, clothing and luggage, etc.) could ignite if allowed to come into contact with the hot exhaust pipe.


Do not permit flammable materials to come into contact with the hot exhaust system. ◀

 Cooling would be inadequate if the engine were allowed to idle for a lengthy period with the motorcycle at a standstill: overheating would result. In extreme cases, the motorcycle could catch fire. Do not allow the engine to idle unnecessarily. Ride away immediately after starting the engine. ◀

Tampering with the engine control unit

 Tampering with the engine control unit can damage the motorcycle and cause accidents.

Do not tamper with the engine control unit. ◀

 Tampering with the engine control unit can result in mechanical loads that the motorcycle's components are not designed to withstand. Damage caused in this way is not covered by the warranty. Do not tamper with the engine control unit. ◀

Checklist

Use the following checklist to check important functions, settings and wear limits before you ride off.

- Brakes
- Brake-fluid levels, front and rear
- Clutch
- Clutch fluid level
- Shock absorber setting and spring preload
- Tyre-tread depth and tyre pressures
- Cases correctly installed and luggage secured

At regular intervals:

- Engine oil level (every refuelling stop)
- Brake-pad wear (every third refuelling stop)

Starting

Side stand

You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if you start it with the gearbox in neutral and then

engage a gear before retracting the side stand.

Gearbox

You can start the engine when the gearbox is in neutral or if you pull the clutch with a gear engaged. Do not pull the clutch until after you have switched on the ignition, as otherwise the engine will refuse to start.

Starting engine.

- Switch on the ignition.
 - » Pre-ride check is performed. (➔ 73)
 - with BMW Motorrad Integral ABS II^{OE}
 - » ABS self-diagnosis is performed. (➔ 73)
 - with Automatic Stability Control^{SA}
 - » ASC self-diagnosis is performed. (➔ 74)



- Press starter button 1.

▶ If ambient temperatures are very low, you might find it necessary to open the throttle slightly when starting the engine. At ambient temperatures below 0 °C, disengage the clutch after switching on the ignition.◀

▶ The start attempt is automatically interrupted if battery voltage is too low. Recharge the battery before you start the engine, or use jump leads and a donor battery to start.◀

- » The engine starts.

- » Consult the troubleshooting chart below if the engine refuses to start. (➔ 136)

Pre-ride check

The instrument panel runs a test of the 'General' warning light when the ignition is switched on: this is the "Pre-Ride-Check". The test is aborted if you start the engine before it completes.

For initialisation, the exhaust flap is opened fully once and then closed again.

Phase 1



General warning light shows red.

- CHECK ! appears on the display.

Phase 2



General warning light shows yellow.

- CHECK ! appears on the display.

If the 'General' warning light does not show:



Some malfunctions cannot be indicated if the 'General' warning light cannot be displayed.

Check that the 'General' warning light comes on, and that it shows red and yellow.◀

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ABS self-diagnosis

- with BMW Motorrad Integral ABS II^{OE}

BMW Motorrad Integral ABS performs self-diagnosis to ensure its operability. Self-diagnosis is performed automatically when you

switch on the ignition. The motorcycle has to move forward a few metres for the wheel sensors to be tested.

Phase 1

- » Test of the diagnosis-compatible system components with the motorcycle at a standstill.



ABS warning light flashes.

Phase 2

- » Test of the wheel sensors as the motorcycle pulls away from rest.



ABS warning light flashes.

ABS self-diagnosis completed

- » The ABS warning light goes out.

If an indicator showing an ABS fault appears when ABS self-diagnosis completes:

- You can continue to ride. Bear in mind that neither the ABS function nor the integral braking function is available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

ASC self-diagnosis

– with Automatic Stability Control^{SA}

BMW Motorrad ASC performs self-diagnosis to ensure its operability. Self-diagnosis is performed automatically when you switch on the ignition. The engine must be running and the motorcycle must reach a speed of at least 5 km/h in order for ASC self-diagnosis to complete.

Phase 1

» Test of the diagnosis-compatible system components with the motorcycle at a standstill.



ASC symbol flashes.

Phase 2

» Test of the diagnosis-compatible system components while the motorcycle is on the move.



ASC symbol flashes.

ASC self-diagnosis completed

» The ASC symbol no longer shows.

If an indicator showing an ASC fault appears when ASC self-diagnosis completes:

- You can continue to ride. Bear in mind that the ASC function is not available.

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Running in

The first 1000 km


- While running in the motorcycle, vary the throttle opening and engine-speed range frequently.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads, avoiding high-speed main roads and highways if possible.



Exceeding the specified engine speeds while running in will lead to increased engine wear.

Keep to the specified engine speeds for running in. ◀

- Do not exceed the rpm limits recommended for running in.


| |
|---|
|  Running-in speed |
|---|

| |
|---------------------------|
| – <7000 min ⁻¹ |
|---------------------------|

- No full-load acceleration.
- Avoid low engine speeds at full load.
- Do not omit the first inspection after 500 - 1200 km.


Brake pads

New brake pads have to bed down before they can achieve their optimum friction levels. You can compensate for this initial reduction in braking efficiency by exerting greater pressure on the levers.

- 
 New brake pads can extend stopping distance by a significant margin. Apply the brakes in good time.◀

Tyres

New tyres have a smooth surface. This must be roughened by riding in a restrained manner at various heel angles until the tyres are run in. This running in procedure is essential if the tyres are to achieve maximum grip.

- 
 Tyres do not have their full grip when new and there is a risk of accidents at extreme angles of heel.

Avoid extreme angles of heel.◀

Shifting gear

– with shift assistant^{SA}

Shift assistant

Your motorcycle is equipped with a shift assistant evolved from motorcycle-racing technology; the shift assistant enables you to upshift in virtually all load and engine-rpm ranges without pulling the clutch or changing the

throttle-valve angle. The throttle valve remains open to accelerate the motorcycle and upshift time is reduced to a minimum. You select the gear in the usual way by means of the foot-operated shift lever.



Sensor **1** in the shift linkage registers the shift request and triggers shift assistance.

When you are riding at constant speed with the engine revving high in a low gear, upshifting without disengaging the clutch can cause a severe reaction to

the load change. BMW Motorrad recommends disengaging the clutch for upshifts in these circumstances. It is advisable to avoid using the shift assistant at engine speeds close to the limits at which the governor cuts in to limit engine rpm.

Shift assistance is not available in the following situations:

- Gearshifts with the clutch pressed
- Gearshifts with the throttle valve closed (engine overrun)
- Downshifts

Brakes

How can stopping distance be minimised?

Each time the brakes are applied, a load distribution shift takes place with the load shifting forward from the rear to the front wheel. The sharper the motorcycle decelerates, the more load

is shifted to the front wheel. The higher the wheel load, the more braking force can be transmitted without the wheel locking.

To optimise stopping distance, apply the front brakes rapidly and keep on increasing the force you apply to the brake lever. This makes the best possible use of the dynamic increase in load at the front wheel. Remember to pull the clutch at the same time. In the "panic braking situations" that are trained so frequently braking force is applied as rapidly as possible and with the rider's full force applied to the brake levers; under these circumstances the dynamic shift in load distribution cannot keep pace with the increase in deceleration and the tyres cannot transmit the full braking force to the surface of the road. ABS has to intervene to keep the front

wheel from locking; this increases stopping distance.

Descending mountain passes



There is a danger of the brakes fading if you use only the rear brakes when descending mountain passes. Under extreme conditions, the brakes could overheat and suffer severe damage.

Use both front and rear brakes, and make use of the engine's braking effect as well. ◀

- with BMW Motorrad Integral ABS II^{OE}




There is a danger of the brakes fading if you use only the rear brakes when descending mountain passes. Under extreme conditions, the brakes could overheat and suffer severe damage.

With the BMW integrated


brake system, the rear brake is activated when the handbrake lever is pressed. This protects against overheating. Only use the front brake and utilise engine braking.◀◀

Wet brakes

 After the motorcycle has been washed, ridden through water or ridden in the rain, the brake discs and pads might be wet and the brakes might not take effect immediately.


Apply the brakes in good time until the brake discs and brake pads have dried out.◀

Salt on brakes

 The brakes may fail to take effect immediately if the motorcycle was ridden on salt-covered roads and the brakes were not applied for some time. Apply the brakes in good time


until the salt layer on the brake discs and brake pads has been removed.◀

Oil or grease on brakes


 Oil and grease on the brake discs and pads considerably diminish braking efficiency.

Especially after repair and maintenance work, make sure that the brake discs and brake pads are free of oil and grease.◀

Dirt or mud on brakes

 When riding on loose surfaces or muddy roads, the brakes may fail to take effect immediately because of dirt or moisture on the discs or brake pads.


Apply the brakes in good time until the brakes have been cleaned.◀

 The brake pads will wear more rapidly if you ride frequently on unsurfaced tracks or poor roads.

Check the thickness of the brake pads more frequently and replace the brake pads in good time.◀

Parking your motorcycle


Placing motorcycle on side stand

 If the ground is soft or uneven, there is no guarantee that the motorcycle will rest firmly on the stand.

Always check that the ground under the stand is level and firm.◀


- Switch off the engine.
- Pull the handbrake lever.
- Hold the motorcycle upright and balanced.

- Use your left foot to extend the side stand fully.

 The side stand is designed to support only the weight of the motorcycle.


Do not lean or sit on the motorcycle with the side stand extended. ◀

- Slowly lean the motorcycle to the side until its weight is taken by the stand and dismount to the left.

 If the motorcycle is on the side stand, the surface of the ground will determine whether it is better to turn the handlebars to the left or right. However, the motorcycle is more stable on a level surface with the handlebars turned to the left than with the handlebars turned to the right.

On level ground, always turn the handlebars to the left to set the steering lock. ◀


- Turn the handlebars to full left or right lock.
- Check that the motorcycle is standing firmly.

 On a gradient, the motorcycle should always face uphill; select 1st gear. ◀

- Lock the steering lock.

Removing motorcycle from side stand

- Unlock the steering lock.
- From the left, grip the handlebars with both hands.
- Pull the handbrake lever.
- Swing your right leg over the seat and lift the motorcycle to the upright position.
- Hold the motorcycle upright and balanced.


 An extended side stand can catch on the ground when the motorcycle is moving and lead to a fall.

Retract the side stand before moving the motorcycle. ◀

- Sit on the motorcycle and use your left foot to retract the side stand.

Placing motorcycle on centre stand

– with centre stand^{OA}


 If the ground is soft or uneven, there is no guarantee that the motorcycle will rest firmly on the stand.

Always check that the ground under the stand is level and firm. ◀

- Switch off the engine.
- Dismount and keep your left hand on the left handlebar grip.
- Grip the rear frame with your right hand.
- Use your right foot on the pin of the centre stand to press

the stand down until its curved feet touch the ground.

- Place your full body weight on the centre stand and at the same time pull the motorcycle to the rear.

 Excessive movements could cause the centre stand to retract, and the motorcycle would topple in consequence.

Do not lean or sit on the motorcycle with the centre stand extended.◀

- Check that the motorcycle is standing firmly.
- Lock the steering lock.


Removing motorcycle from centre stand

– with centre stand^{OA}


- Unlock the steering lock.
- Place your left hand on the left handlebar grip.

- With your right hand, grip the rear grab handle or the rear frame.
- Push the motorcycle forward off the centre stand.
- Check that the centre stand has fully retracted.


Refuelling

 Fuel is highly flammable. A naked flame close to the fuel tank can cause a fire or explosion.


Do not smoke. Never bring a naked flame near the fuel tank.◀


 Fuel expands when hot. Fuel escaping from an overfilled tank could make its way onto the road surface. This could cause a fall.

Do not fill the tank past the bottom edge of the filler neck.◀

 Fuel attacks plastics, which become dull or unsightly. Wipe off plastic parts immediately

if they come into contact with fuel.◀

 Fuel can attack the material of the windscreen, which becomes dull or unsightly. Wipe off the windscreen immediately if it comes into contact with fuel.◀

 Leaded fuel will destroy the catalytic converter. Use only unleaded fuel.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Open the cover of the fuel-tank cap.



- Open the fuel tank cap with the ignition key by turning it counter-clockwise.



- Refuel with fuel of the grade stated below; do not fill the

tank past the bottom edge of the filler neck.

- ▶ When refuelling after running on reserve, make sure that you top up the tank to a level above reserve, as otherwise the sensor will not be able to register the new level. If the sensor cannot register the new level neither the fuel-level reading nor the range readout can be updated.◀



Recommended fuel grade

- 98 ROZ/RON (Premium plus unleaded)
- 95 ROZ/RON (Premium unleaded (fuel grade, usable with power- and consumption-related restrictions))



Usable fuel capacity

– approx. 19 l



Reserve fuel

– ≥4 l

- Press the fuel tank cap down firmly to close.
- Remove the key and close the protective cap.

Securing motorcycle for transportation

- Make sure that all components that might come into contact with straps used to secure the motorcycle are adequately protected against scratching. Use adhesive tape or soft cloths, for example, for this purpose.



⚠ The motorcycle can topple and fall on its side.

Make sure that the motorcycle cannot topple sideways.◀

- Push the motorcycle onto the transportation flat and hold it in position: do not place it on the side stand or centre stand.



⚠ Risk of damaging components.

Take care not to trap components such as brake lines or wires.◀

- At the front, place the strap over the frame and route it downwards.
- Feed the strap forwards through the wheel carrier and tighten it downwards.



- At the rear, secure the straps to the rear footrests on both sides and tighten the straps.
- Tighten all the straps uniformly; the motorcycle's suspension should be compressed as tightly as possible front and rear.

Engineering details

| | |
|---|----|
| Brake system with BMW Motorrad Integral ABS | 84 |
| Electronic engine management with BMW Motorrad ASC | 86 |
| Tyre pressure monitoring RDC | 88 |
| Electronic Suspension Adjustment ESA II | 89 |

Brake system with BMW Motorrad Integral ABS

Partially integral brakes

Your motorcycle is equipped with partially integral brakes. Both front and rear brakes are applied when you pull the handbrake lever. The footbrake lever acts only on the rear brake.

While the brakes are slowing the motorcycle, the BMW Motorrad Integral ABS adapts braking-force distribution between front and rear brakes to suit the load on the motorcycle.



The integral braking function makes it very difficult to spin the rear wheel by opening the throttle with the front brake applied to keep the motorcycle stationary (burn-out). Attempted burn-outs can result in damage to the rear brake and the clutch. Do not attempt burn-outs. ◀

How does ABS work?

The amount of braking force that can be transferred to the road depends on factors that include the coefficient of friction of the road surface. Loose stones, ice and snow or a wet road all have much lower coefficients of friction than a clean, dry asphalt surface. The lower the coefficient of friction, the longer the braking distance.

If the rider increases braking pressure to the extent that braking force exceeds the maximum transferrable limit, the wheels start to lock and the motorcycle loses its directional stability; a fall is imminent. Before this situation can occur, ABS intervenes and adapts braking pressure to the maximum transferrable braking force, so the wheels continue to turn and directional stability is maintained irrespective of the condition of the road surface.

What are the effects of surface irregularities?

Humps and surface irregularities can cause the wheels to lose contact temporarily with the road surface; if this happens the braking force that can be transmitted to the road can drop to zero. If the brakes are applied under these circumstances the ABS has to reduce braking force to ensure that directional stability is maintained when the wheels regain contact with the road surface. At this instant the BMW Motorrad Integral ABS must assume an extremely low coefficient of friction, so that the wheels will continue to rotate under all imaginable circumstances, because this is the precondition for ensuring directional stability. As soon as it registers the actual circumstances, the system reacts instantly and adjusts brak-

ing force accordingly to achieve optimum braking.

What feedback does the rider receive from the BMW Motorrad Integral ABS?

If the ABS system has to reduce braking force on account of the circumstances described above, vibration is perceptible through the handbrake lever.

When the handbrake lever is pulled, brake pressure is also built up at the rear wheel by the integral function. If the brake pedal is depressed after the handbrake lever is pulled, the brake pressure built up beforehand is perceptible as counter-pressure sooner than is the case when the brake pedal is depressed either before or at the same time as the brake lever is pulled.

Rear wheel lift

Even under severe braking, a high level of tyre grip can mean that the front wheel does not lock up until very late, if at all. Consequently, ABS does not intervene until very late, if at all. Under these circumstances the rear wheel can lift off the ground, and the outcome can be a high-siding situation in which the motorcycle can flip over.



Severe braking can cause the rear wheel to lift off the ground.

When you brake, bear in mind that ABS control cannot be relied on in all circumstances to prevent the rear wheel from lifting clear of the ground.◀

What is the design baseline for BMW Motorrad Integral ABS?

Within the limits imposed by physics, the BMW Motorrad Integral ABS ensures directional stability on any surface. The system is not optimised for special requirements that apply under extreme competitive situations off-road or on the track.

Special situations

The speeds of the front and rear wheels are compared as one means of detecting a wheel's incipient tendency to lock. If the system registers implausible values for a lengthy period the ABS function is deactivated for safety reasons and an ABS fault message is issued. Self-diagnosis has to complete before fault messages can be issued. In addition to problems with the BMW Motorrad Integral ABS,

exceptional riding conditions can lead to a fault message being issued.

Exceptional riding conditions:

- Heating up with the motorcycle on the centre stand or an auxiliary stand, engine idling or with a gear engaged.
- Rear wheel locked by the engine brake for a lengthy period, for example while descending off-road.

If a fault message is issued on account of exceptional riding conditions as outlined above, you can reactivate the ABS function by switching the ignition off and on again.

What significance devolves on regular maintenance?



Invariably, a technical system cannot perform beyond the abilities dictated by its level of maintenance.

In order to ensure that the BMW Motorrad Integral ABS is always maintained in optimum condition, it is essential for you to comply strictly with the specified inspection intervals. ◀

Reserves for safety

The potentially shorter braking distances which BMW Motorrad Integral ABS permits must not be used as an excuse for careless riding. ABS is primarily a means of ensuring a safety margin in genuine emergencies.

Take care when cornering. When you apply the brakes on a corner, the motorcycle's weight and

momentum take over and even BMW Motorrad Integral ABS is unable to counteract their effects.

Electronic engine management with BMW Motorrad ASC

- with Automatic Stability Control^{SA}

How does ASC work?

The BMW Motorrad ASC compares the speed of rotation of the front wheel and the rear wheel. The differential is used to compute slip as a measure of the reserves of stability available at the rear wheel. If slip exceeds a certain limit the electronic engine management system intervenes, adapting engine torque accordingly.

What is the design baseline for BMW Motorrad ASC?

BMW Motorrad ASC is designed as an assistant system for the rider and for use on public roads. The extent to which the rider affects ASC control can be considerable (weight shifts when cornering, items of luggage loose on the motorcycle), especially when style of riding takes rider and machine close to the limits imposed by physics.

The system is not optimised for special requirements that apply under extreme competitive situations off-road or on the track. You have the option of deactivating the BMW Motorrad ASC system for these circumstances.



Even ASC is constrained by the laws of physics. Invariably, the rider bears responsibility for assessing road and traffic

conditions and adopting his or her style of riding accordingly. Do not take risks that would negate the additional safety offered by this system. ◀

Special situations

In accordance with the laws of physics, the ability to accelerate is restricted more and more as the angle of heel increases. Consequently, there can be a perceptible lag in acceleration out of very tight bends.

The speeds of the front and rear wheels are compared as one means of detecting the rear wheel's incipient tendency to spin or slip sideways. If the system registers implausible values for a lengthy period the ASC function is deactivated for safety reasons and an ASC fault message is issued. Self-diagnos-

is has to complete before fault messages can be issued. The BMW Motorrad ASC can shut down automatically under the exceptional riding conditions outlined below.

Exceptional riding conditions:

- Riding for a lengthy period with the front wheel lifted off the ground (wheelie) and ASC deactivated.
- Rear wheel rotating with the motorcycle held stationary by applying the front brake (burn-out).
- Heating up with the motorcycle on the centre stand or an auxiliary stand, engine idling or with a gear engaged.

Accelerating the motorcycle to a speed in excess of 10 km/h after switching the ignition off and then on again reactivates the ASC.

If the front wheel lifts clear of the ground under severe acceleration, the ASC reduces engine torque until the front wheel regains contact with the ground. Under these circumstances, BMW Motorrad recommends rolling the throttle slightly closed so as to restore stability with the least possible delay.

When riding on a slippery surface, never snap the throttle twistgrip fully closed without pulling the clutch at the same time. Engine braking torque can cause the rear wheel to lock, with a corresponding loss of stability. The BMW Motorrad ASC is unable to control a situation of this nature.

Tyre pressure monitoring RDC

– with tyre pressure monitoring (RDC)^{OE}

Function

A sensor integrated into each tyre measures the air temperature and the air pressure inside the tyre and transmits this information to the control unit. Each sensor has a centrifugal-force tripswitch that does not enable transmission of the measured values until the motorcycle has accelerated to about 30 km/h. The display shows -- for each tyre until the tyre-pressure signal is received for the first time. The sensors continue to transmit the measured-value signals for approximately 15 minutes after the motorcycle comes to a stop.

The control unit can administer four sensors, so two dif-

ferent sets of wheels with RDC sensors can be alternated on the motorcycle. An error message is issued if wheels without sensors are fitted to a motorcycle equipped with an RDC control unit.

Tyre-pressure ranges

The RDC control unit differentiates between three tyre-pressure ranges, all of which are parameterised for the motorcycle:

- Tyre pressure within permitted tolerance.
- Tyre pressure close to limit of permitted tolerance.
- Tyre pressure outside permitted tolerance.

A warning is also issued if tyre pressure drops sharply but stays within the permitted tolerance.

Temperature compensation

Tyre pressure is a temperature-sensitive variable: pressure increases as tyre temperature rises and decreases as tyre temperature drops. Tyre temperature depends on ambient temperature, on the style of riding and the duration of the ride.

The tyre-pressure readings shown by the multifunction display are temperature-compensated; the reference tyre temperature for these readings is always 20 °C. The air lines available to the public in petrol stations and motorway service areas have gauges that do not compensate for temperature; the reading shown by a gauge of this nature is the temperature-dependent tyre pressure. In most instances, therefore, these gauge readings will not tally with

the pressures shown by the multifunction display.

Pressure adaptation

Compare the RDC readings on the multifunction display with the value in the table on the inside cover of the Rider's Manual. Then use the air line to compensate for the difference between the RDC reading and the value in the table.

Example: According to the Rider's Manual, tyre pressure should be 2.5 bar, but the reading in the multifunction display is 2.3 bar, so pressure is low by 0.2 bar. The gauge on the air line shows 2.4 bar. You must now increase tyre pressure by the 0.2 bar difference between the value in the table and the RDC reading; when the air-line gauge shows 2.6 bar, the tyre is inflated to the correct pressure.

Electronic Suspension Adjustment ESA II

– with Electronic Suspension Adjustment (ESA II)^{OE}

Suspension adjustments

Depending on the load on the motorcycle, the appropriate load status must first be selected when the motorcycle is stationary. The damping characteristics on both spring struts and the spring mount and the spring rate on the rear spring strut are adjusted on the basis of the riding mode that is then selected. If the selected driving mode is changed, the damping characteristics on both spring struts and the spring rate on the rear spring strut are also adjusted. This allows the suspension to be very accurately adapted to all riding conditions, even when the motorcycle is in motion.

- The combination of spring mount, suspension and spring rate ensure that the suspension geometry is always perfectly adjusted.
- The static normal position is almost maintained even while riding.
- The different riding conditions and load statuses are compensated, so that the handling of the motorcycle remains constant.

It is possible to change the spring rate electronically by combining a conventional coil spring and a plastic element (Elastogran), the lateral expansion of which can be restricted electro-hydraulically using a displaceable sleeve. The more the sleeve encloses the plastic element, the more the expansion of the plastic element is restricted, causing the spring

rate to increase. The maximum spring rate is achieved when the sleeve completely encloses the plastic element and rests on the steel spring. By the same token, the spring rate decreases when the sleeve allows the plastic element to expand further.

Accessories

| | |
|---------------------------|----|
| General instructions..... | 92 |
| Power socket | 92 |
| Luggage | 93 |
| Case | 94 |

General instructions

BMW Motorrad recommends the use of parts and accessories for your motorcycle that are approved by BMW for this purpose. Genuine BMW parts and accessories and other products which BMW has approved can be obtained from your authorised BMW Motorrad dealer, together with expert advice on their installation and use.

These parts and products have been tested by BMW for safety, function and suitability. BMW accepts product liability for them. Conversely, BMW is unable to accept any liability whatsoever for parts and accessories which it has not approved.

Also bear in mind the information on the effect of wheel size on suspension-control systems (➔ 108).



BMW Motorrad cannot assess each non-BMW product to determine whether it can be used on or in connection with BMW motorcycles without constituting a safety hazard. Country-specific official authorisation does not suffice as assurance. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW motorcycles and, consequently, they are not sufficient in some circumstances.

Use only parts and accessories approved by BMW for your motorcycle. ◀

Whenever you are planning modifications, comply with all the legal requirements. Make sure that the motorcycle does not infringe the national road-vehicle construction and use regulations applicable in your country.

Power socket

Ratings



The supply to the socket **1** is cut off automatically if battery voltage is too low or the load exceeds the maximum rating.

Operating electrical accessories


You can start using electrical accessories only when the ignition is switched on. The accessory remains operational if the ignition is subsequently switched off. In order to ensure that the drain on the on-board power supply sys-

tem is minimised, the supply to the power socket is cut off approximately 15 minutes after the ignition is switched off, and it is also temporarily interrupted during the start procedure.

Cable routing


The cables from the power socket to the auxiliary device must be routed in such a way that they:

- Do not impede the rider
- Do not restrict or obstruct the steering angle and handling characteristics
- Cannot be trapped

 Incorrectly routed cables can impede the rider. Route the cables as described above.◀


Luggage

Correct loading


 Overloading and imbalanced loads can adversely affect the motorcycle's handling. Do not exceed the permissible gross weight and be sure to comply with the instructions on loading.◀

- Set spring preload, damping characteristic and tyre pressures to suit total weight.
 - with case^{OA}
- Ensure that the case volumes on the left and right are equal.
- Make sure that the weight is uniformly distributed between right and left.
- Pack heavy items at the bottom and toward the inboard side.
- Note the maximum permissible payload of the cases and the

speed limit for riding with cases on the motorcycle.


 Payload of cases

– see label in case

 Maximum permissible speed for riding with cases fitted to the motorcycle

– see label in case◀

- with tank rucksack^{OA}
- Note the maximum permissible payload of the tank rucksack and the speed limit for riding with a tank rucksack on the motorcycle.

 Payload of tank rucksack

– max 5 kg



Maximum permissible speed for riding with the tank rucksack fitted to the motorcycle

– max 130 km/h<

– with tankbag^{OA}

- Note the maximum permissible payload of the tankbag and the speed limit for riding with a tankbag on the motorcycle.



Payload of tankbag

– ≤5 kg




Maximum permissible speed for riding with the tankbag fitted to the motorcycle

– ≤130 km/h<

Case

– with case^{OA}

Opening cases




- Turn the lock barrel to the OPEN position.



- Pull the grey release lever **1** (OPEN) up.
- » Lock straps **2** open.
- Pull the grey release lever (OPEN) up again and simultaneously pull case lid **3** out of the retainer.

Closing cases



- Press catches **1** of the case lid into retainers **2** until they snap closed.
- Also press the catches of the lock straps into retainers **2** until they snap closed.

Adjusting case volume

- Close only the lid of the case.




- Push lock straps **1** out and pull them up.
 - » This expands the case to maximum volume.



- Close the lock straps.

- Press the case lid against the case body.
 - » The case volume adapts to the contents.

Removing cases



- Turn the lock barrel in the RE-LEASE direction.



- Pull the black release lever **1** (RELEASE) up and simultaneously pull the case out.
- Then lift the case out of the bottom holder.

Installing case




- Hook the case into the bottom holder.
- Pull the black release lever **1** (RELEASE) up and simultaneously push the case into the upper holder **2**.
- Push the black release lever (RELEASE) down.
- Check that the case is secure.

Secure attachment



If a case wobbles or is difficult to fit, it has to be adapted to the gap between the top and bottom holders.



Screws **1** inside the case allow you to make this adjustment.

Maintenance

| | |
|---------------------------|-----|
| General instructions..... | 100 |
| Toolkit | 100 |
| Engine oil | 101 |
| Brake system | 102 |
| Brake pads | 103 |
| Brake fluid | 105 |
| Clutch | 106 |
| Tyres | 107 |
| Rims | 108 |
| Wheels | 108 |
| Front-wheel stand | 117 |
| Rear-wheel stand | 118 |
| Bulbs | 119 |
| Jump starting | 125 |
| Battery..... | 126 |

General instructions

The Maintenance chapter describes straightforward procedures for checking and replacing certain wear parts.


Special tightening torques are listed as applicable. The tightening torques for the threaded fasteners on your motorcycle are listed in the section entitled "Technical data".

You will find information on more extensive maintenance and repair work in the Repair Manual on DVD for your motorcycle, which is available from your authorised BMW Motorrad dealer.

Some of the work calls for special tools and a thorough knowledge of motorcycle technology. If you are in doubt consult a specialist workshop, preferably your authorised BMW Motorrad dealer.

Toolkit


Standard toolkit



- 1** Reversible-blade screwdriver with star-head and plain tips
– Removing battery (➔ 127).
- 2** Torx bit, T25
– Removing battery-compartment cover (➔ 128).
- 3** Small screwdriver with star-head tip
– Replacing turn indicator bulbs, front and rear (➔ 123).

Service toolkit

– with service toolkit^{OA}



- 1** Extending tool holder holds all tools by means of adapters, and for removing the spark plug
- 2** 1/4" bits
Bits of various sizes
- 3** 3/8" adapter for socket-head screws, w/f 22
for removing the quick-release axle from the front wheel
- 4** Electric torch

- 5 Socket
Open-ended spanners of various sizes
- 6 Adapter
To accommodate the 1/4" bits and the 9x12 mm and the 3/8" universal-joint adapter

Engine oil

Checking engine oil level



The engine can seize if the oil level is low, and this can lead to accidents.

Always make sure that the oil level is correct.◀



Oil can collect in the sump if the motorcycle is out of use for an extended period of time; this oil has to be pumped into the oil tank before the level is read. The engine oil must be at operating temperature to do this. Checking the oil level with the engine cold or after no more

than a short ride will lead to misinterpretation; this in turn, means that the engine will be operated with the incorrect quantity of oil. In order to ensure that the engine oil level is read correctly, check the oil level only after a lengthy trip.◀

- Make sure the engine is at operating temperature and hold the motorcycle upright.
 - with centre stand^{OA}
- Check that the engine is at operating temperature, make sure the ground is level and firm and place the motorcycle on its centre stand.<
- Allow the engine to idle for one minute.
- Switch off the ignition.



- Check the oil level in oil-level indicator **1**.



Engine oil, specified level

– Between MIN and MAX marks

If the oil level is below the MIN mark:

- Top up the engine oil (⇒ 102).

If the oil level is above the MAX mark:

- Have the oil level corrected by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Topping up engine oil

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the seat (⇒ 66).
- Wipe the area around the filler neck clean.



- Remove cap **1** from the oil filler neck.



Damage to the engine can result if it is operated without enough oil, but the same also applies if the oil level is too high.


Always make sure that the oil level is correct. ◀

- Top up the engine oil to the specified level.
- Check the engine oil level (⇒ 101).
- Install cap **1** of the oil filler neck.
- Install the seat (⇒ 67).

Brake system Reliability

A fully functional brake system is a basic requirement for the road safety of your motorcycle.

Do not ride the motorcycle if you have any doubts about the dependability of the brake system. Under these circumstances have the brake system checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

 Incorrect working practices endanger the reliability of the brakes.

Have all work on the brake system performed by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀


Check operation of the brakes

- Pull the handbrake lever.
 - » The pressure point must be clearly perceptible.
- Press the footbrake lever.
 - » The pressure point must be clearly perceptible.


Brake pads

Checking front brake pad thickness

- Make sure the ground is level and firm and place the motorcycle on its stand.




- Visually inspect the left and right brake pads to ascertain their thickness. Viewing direction: Between wheel and front suspension toward brake caliper **1**.



 Brake-pad wear limit, front

- min 1 mm (Friction pad only, without backing plate. The wear indicators (grooves) must be clearly visible.)

If the wear indicating marks are no longer clearly visible:

 Brake pads worn past the minimum permissible thickness can cause a reduction in braking efficiency and under certain circumstances they can

cause damage to the brake system.

In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness.◀

- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Checking rear brake pad thickness

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the brake pads to ascertain their thickness. Viewing direction: from the right toward brake caliper **1**.



Brake-pad wear limit, rear

- min 1.0 mm (Friction pad only, without backing plate. Make sure that the brake disc is not visible through the bore in the inboard brake pad.)

If the brake disc is visible:



Brake pads worn past the minimum permissible thickness can cause a reduction in braking efficiency and under certain circumstances they can

cause damage to the brake system.

In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible thickness.◀

- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Brake fluid

Checking brake-fluid level, front brakes



A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency.

Check the brake-fluid level at regular intervals.◀

- Make sure the ground is level and firm and hold the motorcycle upright.
 - with centre stand^{OA}
- Make sure the ground is level and firm and place the motorcycle on its centre stand.<
- Move the handlebars to the straight-ahead position.



- Check the brake fluid level in brake fluid reservoir **1**.

▶ Wear of the brake pads causes the brake fluid level in the reservoir to sink.◀



Brake fluid level, front

– DOT4 brake fluid

– Do not permit the brake fluid level to drop below the MIN mark. (Brake-fluid reservoir horizontal, motorcycle upright and handlebars centred)


If the brake fluid level drops below the permitted level:

- Have the defect rectified as quickly as possible by a specialist workshop, preferably

an authorised BMW Motorrad dealer.

Checking brake-fluid level, rear brakes

- Make sure the ground is level and firm and hold the motorcycle upright.
- with centre stand^{OA}
- Make sure the ground is level and firm and place the motorcycle on its centre stand.◁



! A low fluid level in the brake reservoir can allow air to penetrate the brake system.

This significantly reduces braking efficiency.

Check the brake-fluid level at regular intervals.◀

- Check the brake fluid level in rear reservoir **1**.

▷ Wear of the brake pads causes the brake fluid level in the reservoir to sink.◀



Brake fluid level, rear

– DOT4 brake fluid



Brake fluid level, rear

- Do not permit the brake fluid level to drop below the MIN mark. (Brake-fluid reservoir horizontal, motorcycle upright)

If the brake fluid level drops below the permitted level:

- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Clutch

Checking clutch operation

- Pull the clutch lever.
- » The pressure point must be clearly perceptible.

If the pressure point is not clearly perceptible:

- Have the clutch checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Checking clutch fluid level

- Make sure the ground is level and firm and hold the motorcycle upright.
 - with centre stand^{OA}
- Make sure the ground is level and firm and place the motorcycle on its centre stand.◀
- Move the handlebars to the straight-ahead position.



- Check the clutch fluid level in reservoir **1**.

▶ Wear of the clutch causes the fluid level in the clutch fluid reservoir to rise.◀



Clutch-fluid level (visual inspection)

– Do not permit the clutch fluid level to drop.

If the clutch-fluid level drops:



Unsuitable hydraulic fluids could cause damage to the clutch system.

Do not attempt to top up the system with fluids of any kind.◀

- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Tyres

Checking tyre tread depth




Your motorcycle's handling and grip can be impaired even before the tyres wear to the minimum tyre tread depth permitted by law.

Have the tyres changed in good time before they wear to the minimum permissible tread depth.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.

- Measure the tyre tread depth in the main tread grooves with wear marks.

 Tyres have wear indicators integrated into the main tread grooves. The tyre is worn out when the tyre tread has worn down to the level of the marks. The locations of the marks are indicated on the edge of the tyre, e.g. by the letters TI, TWI or by an arrow. ◀

If the tyre tread is worn to minimum:

- Replace tyre or tyres, as applicable.

Rims

Checking rims

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Visually inspect the rims for defects.

- Have damaged rims checked and, if necessary, replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Wheels

Tyre recommendation

For each size of tyre BMW Motorrad tests and classifies as roadworthy certain makes. BMW Motorrad cannot assess the suitability or provide any guarantee of road safety for other tyres.

BMW Motorrad recommends using only tyres tested by BMW Motorrad.

You can obtain detailed information from your authorised BMW Motorrad dealer or on the Internet at www.bmw-motorrad.com.

Effect of wheel size on suspension-control systems

Wheel size is very important as a parameter for the suspension-control systems ABS and ASC. In particular, the diameter and the width of a motorcycle's wheels are programmed into the control unit and are fundamental to all calculations. Any change in these influencing variables, caused for example by a switch to wheels other than those installed ex-works, can have serious effects on the performance of the control systems.


The sensor rings are essential for correct road-speed calculation, and they too must match the motorcycle's control systems and consequently cannot be changed.


If you decide that you would like to fit non-standard wheels to your motorcycle, it is very import-

ant to consult a specialist workshop beforehand, preferably an authorised BMW Motorrad dealer. In some cases, the data programmed into the control units can be changed to suit the new wheel sizes.

RDC label

- with tyre pressure monitoring (RDC)^{OE}



 Incorrect tyre-removal procedures can result in damage to the RDC sensors.


Be sure to notify the authorised BMW Motorrad dealer or spe-

cialist workshop that the wheel is fitted with an RDC sensor. ◀

If the motorcycle is equipped with RDC, each wheel rim bears an adhesive label indicating the position of the RDC sensor. When changing the tyre, take care not to damage the RDC sensor. Be sure to draw the attention of the authorised BMW Motorrad dealer or specialist workshop to the fact that the wheel is fitted with an RDC sensor.

Remove the front wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Remove screws **1** on left and right.
- Remove covers **2** on left and right.

– with BMW Motorrad Integral ABS II^{OE}



- Unclip the two retaining clips **1** holding the ABS sensor cable to the brake line.◀
- Mask off the parts of the wheel rim that could be scratched in the process of removing the brake calipers.



! Once the calipers have been removed, there is a risk of the brake pads being pressed together to the extent that they cannot be slipped back over the brake disc on reassembly.

Do not operate the handbrake lever when the brake calipers have been removed.◀

- Remove securing screws **2** of the left and right brake calipers.



- Force the brake pads **3** slightly apart by rocking brake caliper **4** back and forth against brake disc **5**.
- Carefully pull the brake calipers back and out until clear of the brake discs.

– with BMW Motorrad Integral ABS II^{OE}



- Remove screw **1** and remove the ABS sensor from its bore.<


- Place the motorcycle on an auxiliary stand; BMW Motorrad recommends the BMW Motorrad rear-wheel stand.


- Installing rear-wheel stand (➔ 118).

– with centre stand^{OA}

- Make sure the ground is level and firm and place the motorcycle on its centre stand.<

- Raise front of motorcycle until the front wheel can turn freely. BMW Motorrad recommends the BMW Motorrad front-wheel stand for lifting the motorcycle.
- Installing front-wheel stand (➔ 117).




 The left axle clamping screw locates the threaded bush in the front suspension. If the threaded bush is not correctly aligned the gap between the ABS sensor ring and the ABS sensor will not be correct and this can cause the


ABS to malfunction or allow the ABS sensor to be damaged. In order to ensure that the threaded bush remains correctly aligned, do not slacken or remove the left axle clamping screw.<


- Remove right-hand axle clamping screw **2**.
- Remove quick-release axle **3**, while supporting the wheel.
- Roll the front wheel forward to remove.

Installing front wheel


 Possible malfunctions when ABS and ASC systems intervene if non-standard wheels are installed.

See the information on the effect of wheel size on the ABS and ASC systems at the start of this chapter.<

 Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage. Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

 The front wheel must be installed right way round to rotate in the correct direction. Note the direction-of-rotation arrows on the tyre or the wheel rim. ◀

- Roll the front wheel into position between the front forks.



- Raise the front wheel, insert quick-release axle **3** and tighten to specified torque.



Quick-release axle in threaded bush

– 50 Nm

- Tighten right axle clamping screw **2** to the specified tightening torque.




Clamping bolt in wheel carrier

– 19 Nm

- Remove the front-wheel stand.


- without centre stand^{OA}
- Remove the rear-wheel stand ◀
- with BMW Motorrad Integral ABS II^{OE}



- Insert the ABS sensor into its bore and install screw **1**. ◀
- Ease the brake calipers on to the brake discs.

– with BMW Motorrad Integral
ABS II^{OE}



 The cable of the ABS sensor could chafe through if it comes into contact with the brake disc.

Make sure that the ABS sensor cable is routed correctly. ◀

- Carefully route the ABS cable. Make sure that the ABS sensor cable is clipped into holders **1**. ◀




- Install securing screws **2**.



Front brake caliper to
wheel carrier

– 30 Nm

- Remove the adhesive tape from the wheel rim.
- Firmly pull the handbrake lever until the pressure point is perceptible, and repeat this operation several times.




- Position covers **2** on left and right.
- Install screws **1** on left and right.

Removing rear wheel

– without centre stand^{OA}

- Place the motorcycle on an auxiliary stand; BMW Motorrad recommends the BMW Motorrad rear-wheel stand.
- Installing rear-wheel stand (➔ 118). ◀

- with centre stand^{OA}
- Make sure the ground is level and firm and place the motorcycle on its centre stand.<



- Remove three bolts **1** from silencer cover **2**.
- Remove the cover.



- Slacken bolt **3** on the clamp so that the clamp can just be turned.
- Do not remove the sealing grease from the clamp.



- Remove bolt **4** on the rear footrest while supporting the end silencer.



- First turn the end silencer slightly downwards and then turn it out.

- Engage first gear.



- Remove five bolts **1** from the rear wheel, while supporting the wheel.
- If you are using the BMW Motorrad rear-wheel stand: remove the retaining disc.
- Lower the rear wheel to the ground and roll it out to the rear.
- If you are using the BMW Motorrad rear-wheel stand: reinstall the retaining disc.

Installing rear wheel

! Possible malfunctions when ABS and ASC systems intervene if non-standard wheels are installed.

See the information on the effect of wheel size on the ABS and ASC systems at the start of this chapter. ◀


! Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage. Always have the security of the fasteners checked by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

- If you are using the BMW Motorrad rear-wheel stand: remove the retaining disc.
- Roll the rear wheel into position at the rear-wheel adapter and attach it.

- If you are using the BMW Motorrad rear-wheel stand: reinstall the retaining disc.



- Fit five bolts **1** and tighten to the specified torque in diagonally opposite sequence.

 Rear wheel to wheel flange

– Tightening sequence: tighten in diagonally opposite sequence

– 60 Nm

- Turn the end silencer to its initial position.




- Insert screw **4** into the rear footrest and tighten to the specified tightening torque.



Silencer to rear footrest

– 22 Nm



- Arrange the end silencer so that the handle of the reversible-blade screwdriver (toolkit) can fit between the wheel and the end silencer.




- Position the clamp as shown.

- Tighten screw **3** of the ball-joint clamp to the specified tightening torque.



Silencer with ball-joint clamp on manifold

– 35 Nm



- Hold the silencer cover **2** in position and fit the three bolts **1**.

– without centre stand^{OA}

- Remove the rear-wheel stand◁

Front-wheel stand

Installing front-wheel stand

! The BMW Motorrad front wheel stand is not designed to support motorcycles not fitted with a centre stand or without other auxiliary stands. A motorcycle resting only on the front wheel stand and the rear wheel can topple.

Place the motorcycle on its centre stand or another auxiliary stand before lifting the front wheel with the BMW Motorrad front-wheel stand.◀


- Use basic stand with tool number (0 402 241) in combination with front-wheel adapter (0 402 243).
- without centre stand^{OA}
- Place the motorcycle on an auxiliary stand; BMW Motorrad

recommends the BMW Motorrad rear-wheel stand.

- Installing rear-wheel stand (➔ 118).◀

– with centre stand^{OA}

- Make sure the ground is level and firm and place the motorcycle on its centre stand.◀



- Slacken adjusting screws **1**.
- Push the two pins **2** apart until the front suspension fits between them.
- Use locating pins **3** to set the front-wheel stand to the desired height.

- Centre the front-wheel stand relative to the front wheel and push it against the front axle.



! There is a risk of damaging the sensor ring of the BMW Motorrad Integral ABS. Push the left pin in just far enough to ensure that it clears the sensor ring.◀

- Push both mounting pins **2** through the triangles of the brake caliper anchorages just far enough to allow the front wheel to be rolled between them.

- Tighten adjusting screws **1**.




! If the motorcycle is on the centre stand and is raised too far, the centre stand will lift clear of the ground and the motorcycle could topple to one side. When raising the motorcycle, make sure that the centre stand remains on the ground.◀

- Apply uniform pressure to push the front-wheel stand down and raise the motorcycle.

Rear-wheel stand


Installing rear-wheel stand

- Use basic stand with tool number (0 402 245) in combination with rear-axle adapter (0 402 250).



- Use screws **1** to set the rear-wheel stand to the desired height.
- Remove retaining disc **2**. To do so, press release button **3**.
- Remove retaining disc **2**. To do so, press release button **3**.


- Make sure the ground is level and firm and place the motorcycle on its side stand.



- Push the rear wheel stand from the left into the rear axle.
- Push on retaining disc **2** from the right, while holding the release button down.
- Grip the rear grab handle of the motorcycle with your left hand and use your right to grip the handle of the rear-wheel stand.



- Hold the motorcycle upright and press the handle of the stand backwards so that both wheels of the stand are touching the ground.
- Then press the handle down to the ground.




- In order to ensure secure positioning, fit lever 4 to the short side of the stand.


Bulbs

General instructions


A warning appears in the multi-function display if a bulb is defective. If the brake or rear light fails, the symbol is accompanied by the 'General' warning light, which lights up yellow.


 A defective bulb places your safety at risk because it is easier for other users to oversee the motorcycle.

Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible. ◀

 The bulb is pressurised and can cause injury if damaged.

Wear protective goggles and gloves when changing bulbs. ◀


 The types of bulb fitted to your motorcycle are listed in the section entitled "Technical data". ◀

 Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when handling them. Dirt deposits, in particular oil and grease, interfere with heat radiation from the bulb. This leads to overheating and shortens the bulb's operating life. ◀


Replacing low-beam and high-beam headlight bulb

The plug arrangement can differ from the illustration, depending on the bulb to be replaced. ◀


- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.



- Remove the covers **1** for the high-beam headlight or cover **2** for the low-beam headlight by turning the covers anticlockwise.




- Disconnect plug **3**.




- Disengage spring clip **4** from the latches and swing it up.
- Remove bulb **5**.


- Replace the defective bulb.

| | |
|---|----------------------------------|
|  | Bulbs for the low-beam headlight |
|---|----------------------------------|

| |
|--------------------|
| – H7 / 12 V / 55 W |
|--------------------|

| | |
|---|------------------------------|
|  | Bulb for high-beam headlight |
|---|------------------------------|

| |
|--------------------|
| – H7 / 12 V / 55 W |
|--------------------|




- Install bulb **5**, making sure that tab **6** is correctly positioned.



- Engage spring retainer **4** in the catches.




- Close plug **3**.



- Fit the covers **1** for the high-beam headlight or cover **2** for the low-beam headlight by turning the covers clockwise.

Replacing parking-light bulb

 If it is not standing firmly, the motorcycle could topple in the course of the operations described below.

Always make sure that the motorcycle is stable and firmly supported.◀


- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.





- Remove securing screws **1** from both sides of the bulb housing.




- Pull the bulb housing forward to remove it and tilt it slightly down.
- Remove bulb holder **2** from the headlight housing by turning it counter-clockwise.




- Remove bulb **3** from the bulb holder.
- Replace the defective bulb.



- Insert bulb **3** into the bulb socket.
- Turn the bulb socket clockwise to install it in the headlight housing.



 The headlight cable could catch in the steering if it is not routed correctly.

Use the appropriate retaining clips to secure electric wires at the back of the headlight. ◀

- Push the bulb housing into mounts **4** on the frame.



- Install securing screws **1** at both sides of the bulb housing.

Replacing turn indicator bulbs, front and rear

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.



- Remove screw **1**.



- Pull the glass out of the turn-indicator housing at the threaded-fastener side.




- Press bulb **2** into its socket and turn it counter-clockwise to remove.
- Replace the defective bulb.



Bulbs for flashing turn indicators, rear

– RY10W / 12 V / 10 W



- Press bulb **2** into its socket and turn it clockwise to install.



- Seat the glass in the turn indicator housing.



- Install screw **1**.

LED rear light

If the number of LEDs in the rear light that have failed exceeds the number stated in the Technical Data below, the rear light must be replaced. Under these circumstances:

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.



Maximum number of defective LEDs in rear-light unit

- 1 (Brake/rear light (red))

- 1 (Number-plate light (white))

Jump starting



The wires leading to the power socket do not have a load-capacity rating adequate for jump-starting the engine. Excessively high current can lead to a cable fire or damage to the vehicle electronics.

Do not use the on-board socket to jump-start the engine of the motorcycle. ◀



Touching live parts of the ignition system with the engine running can cause electric shock.

Do not touch parts of the ignition system when the engine is running. ◀



A short-circuit can result if the crocodile clips of the jump leads are accidentally brought into contact with the motorcycle.

Use only jump leads fitted with fully insulated crocodile clips at both ends. ◀



Jump-starting with a donor-battery voltage higher than 12 V can damage the vehicle electronics.

Make sure that the battery of the donor vehicle has a voltage rating of 12 V. ◀

- When jump-starting the engine, do not disconnect the battery from the on-board electrical system.
- Removing battery-compartment cover (➔ 128).
- Run the engine of the donor vehicle during jump-starting.
- Begin by connecting one end of the red jump lead to the

positive terminal of the discharged battery and the other end to the positive terminal of the donor battery.

- Then connect one end of the black jump lead to the negative terminal of the donor battery, and the other end to the negative terminal of the discharged battery.
- Start the engine of the vehicle with the discharged battery in the usual way; if the engine does not start, wait a few minutes before repeating the attempt in order to protect the starter motor and the donor battery.
- Allow both engines to idle for a few minutes before disconnecting the jump leads.
- Disconnect the jump lead from the negative terminals first, then disconnect the second lead from the positive terminals.

- Installing battery-compartment cover (→ 129).

Battery

Maintenance instructions

Correct upkeep, recharging and storage will prolong the life of the battery and are essential if warranty claims are to be considered.

Compliance with the points below is important in order to maximise battery life:

- Keep the surface of the battery clean and dry
- Do not open the battery
- Do not top up with water
- Be sure to read and comply with the instructions for charging the battery on the following pages
- Do not turn the battery upside down



If the battery is not disconnected, the on-board electronics (e.g. clock, etc.) gradually drain the battery. This can cause the battery to run flat. If this happens, warranty claims will not be accepted.

If the motorcycle is to be out of use for more than four weeks, disconnect the battery or connect a suitable trickle charger to the battery.◀



BMW Motorrad has developed a float charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, you can keep the battery charged during long periods of disuse, without having to disconnect the battery from the motorcycle's on-board systems. You can obtain additional information from your authorised BMW Motorrad dealer.◀

Charging battery when connected




Charging the connected battery directly at the battery terminals can damage the vehicle electronics.

Always disconnect the battery from the on-board circuits before recharging it with a charger connected directly to the battery posts.◀




If you switch on the ignition and the multifunction display and telltale lights fail to light up, the battery is completely flat. Attempting to charge a completely flat battery via the on-board socket can cause damage to the motorcycle's electronics. If a battery has discharged to the extent that it is completely flat, it has to be disconnected from the on-board circuits and charged with the charger connected directly to the battery posts.◀


 Only chargers suitable for this mode of charging can be used to recharge the battery via the on-board socket. Unsuitable chargers could cause damage to the motorcycle's on-board electrics.

Use BMW chargers with the part numbers 71 60 7 688 864 (220 V) or, as applicable, 71 60 7 688 865 (110 V). If you are in doubt, disconnect the battery from the on-board systems and connect the charger directly to the battery.◀

- Charge via the power socket, with the battery connected to the motorcycle's on-board electrical system.


 The motorcycle's on-board electronics know when the battery is fully charged. The on-board socket is switched off when this happens.◀

- Comply with the operating instructions of the charger.

 If you are unable to charge the battery through the on-board socket, you may be using a charger that is not compatible with your motorcycle's electronics. If this happens, disconnect the battery from the on-board systems and connect the charger directly to the battery.◀

Charging battery when disconnected

- Charge the battery using a suitable charger.
- Comply with the operating instructions of the charger.
- Once the battery is fully charged, disconnect the charger's terminal clips from the battery terminals.


 The battery has to be recharged at regular intervals in the course of a lengthy period of disuse. See the instructions

for caring for your battery. Always fully recharge the battery before restoring it to use.◀

Removing battery

- Removing battery-compartment cover (→ 128).




 Disconnection in the wrong sequence increases the risk of short-circuits. Always proceed in the correct sequence.◀

- Disconnect negative lead **1** first.


- Then disconnect positive lead **2**.
- Remove screws **3** and pull the retainer to the rear.
- Lift the battery up and out; work it slightly back and forth if it is difficult to remove.

Installing battery


- Place the battery in the battery compartment, positive terminal on the right in the forward direction of travel.



- Slip the battery retainer over the battery and install screws **3**.

 Installation in the wrong sequence increases the risk of short-circuits. Always proceed in the correct sequence. ◀


- Connect battery positive lead **2** first.
- The connect battery negative lead **1**.

 If the battery was disconnected from the motorcycle for a prolonged period of time it will be necessary to enter the current date in the instrument panel, in order to ensure that the service-due indicator functions correctly.

If you want to have the date set consult a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀


- Installing battery-compartment cover (⇒ 129).
- Set the clock (⇒ 48).

Removing battery-compartment cover

 If it is not standing firmly, the motorcycle could topple in the course of the operations described below.


Always make sure that the motorcycle is stable and firmly supported. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Remove screws **1**.
- Lift battery compartment cover **2** up and forward to remove.

Installing battery-compartment cover




- Install battery compartment cover **2**.
- Install screws **1**.

Care

| | |
|---|-----|
| Care products | 132 |
| Washing motorcycle | 132 |
| Cleaning easily damaged components..... | 132 |
| Paint care | 133 |
| Protective wax coating | 134 |
| Laying up motorcycle | 134 |
| Restoring motorcycle to use | 134 |

Care products

BMW Motorrad recommends that you use the cleaning and care products you can obtain from your authorised BMW Motorrad dealer. The substances in BMW CareProducts have been tested in laboratories and in practice; they provide optimised care and protection for the materials used in your vehicle.

 The use of unsuitable cleaning and care products can damage vehicle components. Do not use solvents such as cellulose thinners, cold cleaners, fuel or the like, and do not use cleaning products that contain alcohol.◀

Washing motorcycle


BMW Motorrad recommends that you use BMW insect remover to soften and wash off insects and stubborn dirt on

painted parts prior to washing the motorcycle.


To prevent stains, do not wash the motorcycle immediately after it has been exposed to strong sunlight and do not wash it in the sun.

Make sure that the motorcycle is washed frequently, especially during the winter months.


To remove road salt, clean the motorcycle with cold water immediately after every trip.

 After the motorcycle has been washed, ridden through water or ridden in the rain, the brake discs and pads might be wet and the brakes might not take effect immediately.

Apply the brakes in good time until the brake discs and brake pads have dried out.◀

 Warm water intensifies the effect of salt.

Use only cold water to wash off road salt.◀


 The high pressure of steam cleaners can damage seals, the hydraulic brake system, the electrical system, and the seat. Do not use a steam jet or high-pressure cleaning equipment.◀

Cleaning easily damaged components


Plastics

Clean plastic parts with water and BMW plastic care emulsion. This includes in particular:

- Windscreen and slipstream deflectors
- Headlight lens made of plastic
- Glass cover of the instrument cluster
- Black, unpainted parts


 If plastic parts are cleaned using unsuitable cleaning agents, the surfaces can be damaged.

Do not use cleaning agents that contain alcohol, solvents or abrasives to clean plastic parts. Even fly-remover pads or cleaning pads with hard surfaces can produce scratches.◀

 Soften stubborn dirt and insects by covering the affected areas with a wet cloth.◀

Windscreen

Clean off dirt and insects with a soft sponge and plenty of water.


 Fuel and chemical solvents attack the material of the windscreen; the windscreen becomes opaque or dull. Do not use cleaning agents.◀

Chrome

Use plenty of water and BMW shampoo to clean chrome, particularly if it has been exposed to road salt. Use chrome polish for additional treatment.

Radiator


Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling. For example, use a garden hose with low water pressure.

 Cooling fins can be bent easily.

Take care not to bend the fins when cleaning the radiator.◀

Rubber

Treat rubber components with water or BMW rubber-care products.

 Using silicone sprays for the care of rubber seals can cause damage.

Do not use silicone sprays or other care products that contain silicon.◀

Paint care

Washing the motorcycle regularly will help counteract the long-term effects of substances that damage the paint, especially if your motorcycle is ridden in areas with high air pollution or natural sources of dirt, for example tree resin or pollen.

Remove particularly aggressive substances immediately, however, as otherwise the paint can be affected or become discoloured. Substances of this nature include spilt fuel, oil, grease, brake fluid and bird droppings. We recommend BMW vehicle polish or BMW paint cleaner for this purpose.

Marks on the paintwork are particularly easy to see after the motorcycle has been washed.

Remove stains of this kind immediately, using cleaning-grade benzene or petroleum spirit on a clean cloth or ball of cotton wool. BMW Motorrad recommends BMW tar remover for removing specks of tar. Remember to wax the parts treated in this way.

Protective wax coating

BMW Motorrad recommends applying only BMW car wax or products containing carnauba wax or synthetic wax.

It is time to rewax the paintwork when water "puddles" on the surface, instead of forming beads.

Laying up motorcycle

- Clean the motorcycle.
- Remove the battery.
- Spray the brake and clutch lever pivots and the main and

side stand pivots with a suitable lubricant.

- Coat bright metal and chrome-plated parts with an acid-free grease (e.g. Vaseline).
- Stand the motorcycle in a dry room in such a way that there is no load on either wheel.

▶ Before laying the vehicle up out of use, have the engine oil and the oil filter element changed by a specialist workshop, preferably an authorised BMW Motorrad dealer. Combine work for laying up/restoring to use with a BMW service or inspection.◀

Restoring motorcycle to use

- Remove the protective wax coating.
- Clean the motorcycle.
- Install a charged battery.

- Before starting: work through the checklist.

Technical data

| | |
|-----------------------------|-----|
| Troubleshooting chart | 136 |
| Threaded fasteners | 137 |
| Engine | 139 |
| Fuel | 140 |
| Engine oil | 140 |
| Clutch | 141 |
| Transmission | 141 |
| Rear-wheel drive | 142 |
| Running gear | 142 |
| Brakes | 144 |
| Wheels and tyres | 144 |
| Electrics | 145 |
| Frame | 147 |
| Dimensions | 147 |
| Weights | 148 |

| | |
|-----------------------------|-----|
| Riding specifications | 148 |
|-----------------------------|-----|

Troubleshooting chart

Engine does not start at all or is difficult to start.

| Possible cause | Remedy |
|---|---|
| Side stand | Retract the side stand (➔ 72). |
| Gear engaged and clutch not disengaged | Select neutral or pull clutch lever (➔ 72). |
| Clutch pulled before ignition was switched on | Switch on the ignition, then pull the clutch lever. |
| No fuel in tank | Refuelling (➔ 79). |
| Battery flat | Charge the battery when connected (➔ 126). |

Threaded fasteners

| Front wheel | Value | Valid |
|---|--------------|--------------|
| Front brake caliper to wheel carrier | | |
| M8 x 32 - 10.9 | 30 Nm | |
| Clamping bolt in wheel carrier | | |
| M8 x 30 | 19 Nm | |
| Quick-release axle in threaded bush | | |
| M24 x 1.5 | 50 Nm | |
| Rear wheel | Value | Valid |
| Silencer to rear footrest | | |
| M8 x 30 | 22 Nm | |
| Silencer with ball-joint clamp on manifold | | |
| M8 x 60 | 35 Nm | |
| Cover to silencer | | |
| M5 x 8 | 3 Nm | |

| Rear wheel | Value | Valid |
|-------------------------------------|--|--------------|
| Rear wheel to wheel flange | | |
| M10 x 1.25 x 40 | tighten in diagonally opposite sequence | |
| | 60 Nm | |
| Mirrors | Value | Valid |
| Mirror on left/right adapter | | |
| Left-hand thread, M10 x 1.25 | 22 Nm | |

Engine

| | |
|--|--|
| Engine design | Transversely mounted, four-cylinder four-stroke in-line engine tilted 55° forward, with four valves per cylinder, two overhead camshafts with cam followers; liquid cooled, with electronic fuel injection, integrated six-speed cassette gearbox, dry-sump lubrication. |
| Displacement | 1293 cm ³ |
| Cylinder bore | 80 mm |
| Piston stroke | 64.3 mm |
| Compression ratio | 13:1 |
| Nominal output | 127 kW, - at engine speed: 9250 min ⁻¹ |
| - with reduced power output, 79 kW ^{OE} | 79 kW, - at engine speed: 9000 min ⁻¹ |
| Torque | 140 Nm, - at engine speed: 8250 min ⁻¹ |
| - with reduced power output, 79 kW ^{OE} | 118 Nm, Over: 3750 min ⁻¹ |
| Maximum engine speed | max 11000 min ⁻¹ |
| Idle speed | 1050±50 min ⁻¹ |

Fuel

| | |
|------------------------|---|
| Recommended fuel grade | 98 ROZ/RON, Premium plus unleaded 95 ROZ/RON, Premium unleaded (fuel grade, usable with power- and consumption-related restrictions) |
| Usable fuel capacity | approx. 19 l |
| Reserve fuel | ≥4 l |

Engine oil

| | |
|--|--|
| Engine oil, capacity | 3.5 l, with filter change 0.5 l, Difference between MIN / MAX marks |
| of products recommended by BMW Motorrad and generally admissible viscosity classes | |
| Castrol Power 1 Racing SAE 5W-40 | ≥-20 °C |
| SAE 5W-40 | ≥-20 °C |
| SAE 10W-50 | ≥-20 °C |
| Oil grades | Engine oils of API classification SJ or better. Engine oils of JASO classification MA or better. |

Clutch

| | |
|-------------|---------------------------------------|
| Clutch type | Multiplate clutch running in oil bath |
|-------------|---------------------------------------|

Transmission

| | |
|-----------------------------|---|
| Gearbox type | Claw-shift 6-speed gearbox, integrated into engine block |
| Gearbox transmission ratios | 1.559 (92:59 teeth), Primary transmission ratio 2.294 (39:17 teeth), 1st gear 1.789 (34:19 teeth), 2nd gear 1.458 (35:24 teeth), 3rd gear 1.240 (31:25 teeth), 4th gear 1.094 (35:32 teeth), 5th gear 0.971 (33:34 teeth), 6th gear 1.045 (23:22 teeth), Angular drive |

Rear-wheel drive

| | |
|--|--|
| Type of final drive | Shaft drive with bevel gears |
| Type of rear suspension | BMW EVO Paralever; cast light-alloy single swinging arm with two joints and torque reaction link |
| Number of teeth on rear-wheel drive (gear ratio) | 2.91 (32:11) |

Running gear

Front wheel

| | |
|--|--|
| Type of front suspension | Double leading link |
| Spring strut, front, type | Central spring strut with coil spring and single-tube gas-filled shock absorber. |
| – with Electronic Suspension Adjustment (ESA II) ^{OE} | Central spring strut with single-tube gas-filled shock absorber and electrically adjustable rebound-stage damping. |
| Spring travel, front | 125 mm, At wheel |

Rear wheel

| | |
|--|--|
| Type of rear suspension | BMW EVO Paralever; cast light-alloy single swinging arm with two joints and torque reaction link |
| Type of rear suspension | Central spring strut pivoted to lever system with coil spring and single-tube gas-filled shock absorber. Spring preload steplessly hydraulically adjustable, rebound stage damping steplessly adjustable. |
| – with Electronic Suspension Adjustment (ESA II) ^{OE} | Central spring strut pivoted to lever system with coil spring and single-tube gas-filled shock absorber, electrically adjustable rebound-stage damping and electro-hydraulically adjustable spring preload |
| Spring travel, rear | 135 mm, At wheel |

Brakes

| | |
|---------------------------|--|
| Type of front brake | Hydraulically operated twin disc brake with 4-piston fixed calipers and floating brake discs |
| Brake-pad material, front | Sintered metal |
| Type of rear brake | Hydraulically operated disc brake with 2-piston floating caliper and fixed disc |
| Brake-pad material, rear | Organic material |

Wheels and tyres

| | |
|-----------------------|--|
| Recommended tyre sets | You can obtain an up-to-date list of approved tyres from your authorised BMW Motorrad dealer or on the Internet at " www.bmw-motorrad.com ". |
|-----------------------|--|

Front wheel

| | |
|-------------------------|-----------------------|
| Front wheel, type | Cast aluminium, MT H2 |
| Front wheel rim size | 3.50" x 17" |
| Tyre designation, front | 120 / 70 ZR 17 |

Rear wheel

| | |
|-----------------------------------|-----------------------|
| Rear wheel type | Cast aluminium, MT H2 |
| Rear wheel rim size | 5.5" x 17" |
| – with sports wheel ^{OE} | 6.0" x 17" |
| Tyre designation, rear | 180 / 55 ZR 17 |
| – with sports wheel ^{OE} | 190 / 55 ZR 17 |

Tyre pressure

| | |
|----------------------|--------------------|
| Tyre pressure, front | 2.5 bar, Tyre cold |
| Tyre pressure, rear | 2.9 bar, Tyre cold |

Electrics

| | |
|--------------------------------------|---|
| Electrical rating of on-board socket | max 5 A |
| Fuses | All circuits are electronically protected, so plug-in fuses are no longer necessary. If an electronic fuse trips and de-energises a circuit, the circuit is active as soon as the ignition is switched on after the fault has been rectified. |

Battery

| | |
|---------------------------------------|-----------------------------------|
| Battery, manufacturer and designation | Yuasa YTX 14 BS |
| Battery type | AGM (Absorbent Glass Mat) battery |
| Battery rated voltage | 12 V |
| Battery rated capacity | 14 Ah |

Technical data

| | |
|---|------------------|
| Spark plugs, manufacturer and designation | NGK KR9CI |
| Electrode gap of spark plug | 0.8 mm, When new |

Lighting

| | |
|---|--|
| Bulb for high-beam headlight | H7 / 12 V / 55 W |
| Bulbs for the low-beam headlight | H7 / 12 V / 55 W |
| Bulb for parking light | W5W / 12 V / 5 W |
| Bulb for tail light/brake light | LED / 12 V |
| Maximum number of defective LEDs in rear-light unit | 1, Brake/rear light (red) 1, Number-plate light (white) |
| Bulbs for flashing turn indicators, front | RY10W / 12 V / 10 W |
| Bulbs for flashing turn indicators, rear | RY10W / 12 V / 10 W |

Frame

| | |
|---------------------|--|
| Frame type | Light alloy weldment with bolt-on tubular steel rear frame |
| Type plate location | Frame cross-tube, rear |
| VIN location | Frame side section, front right |

Dimensions

| | |
|--------------------------------------|---|
| Length of motorcycle | 2233 mm |
| Height of motorcycle | 1230 mm, Across mirrors at DIN unladen weight |
| Width of motorcycle | 856 mm, Across mirrors |
| Front-seat height | 820 mm, Without rider |
| – with low double seat ^{SA} | 790 mm, Without rider |
| Rider's inside-leg arc, heel to heel | 1810 mm, Without rider |
| – with low double seat ^{SA} | 1750 mm, Without rider |

Weights

| | |
|--------------------------|--|
| Unladen weight | 243 kg, DIN unladen weight, ready for road, 90 % load of fuel, without optional extras |
| Permissible gross weight | 460 kg |
| Maximum payload | 217 kg |

Riding specifications

| | |
|-----------|-----------|
| Top speed | >200 km/h |
|-----------|-----------|

Service

| | |
|---|-----|
| BMW Motorrad service | 150 |
| BMW Motorrad service quality | 150 |
| BMW Motorrad mobility services - roadside assistance | 150 |
| BMW Motorrad service network | 151 |
| Maintenance work | 151 |
| Confirmation of maintenance work | 152 |
| Confirmation of service | 157 |

BMW Motorrad service

Advanced technology requires specially adapted methods of maintenance and repair.



If maintenance and repair work is performed inexpertly, it could result in consequential damage and thus constitute a safety risk.

BMW Motorrad recommends you to have all the associated work on your motorcycle carried out by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

Your authorised BMW Motorrad dealer can provide information on BMW services and the work undertaken as part of each service. Have all maintenance and repair work carried out confirmed in the "Service" chapter in this manual. Authorised BMW Motorrad dealers are supplied with the latest technical information and have

the necessary technical know-how. BMW Motorrad recommends that you contact your authorised BMW Motorrad dealer if you have questions regarding your motorcycle.

BMW Motorrad service quality

Along with its reputation for engineering quality and high reliability, BMW Motorrad is a byword for excellent quality of service.

To ensure that your BMW is always in optimum condition, BMW Motorrad recommends that you have the maintenance work required for your motorcycle carried out regularly, preferably by your authorised BMW Motorrad dealer. For generous treatment of claims submitted after the warranty period has expired, evidence of regular maintenance is essential.

Certain signs of wear, moreover, may otherwise not be noticed until it is too late to put them right at moderate cost. Your authorised BMW Motorrad dealer's mechanics know every detail of your motorcycle and can take remedial action if necessary before minor faults develop into serious problems. By having the necessary repairs done properly and in good time, you save time and money in the long run.

BMW Motorrad mobility services - roadside assistance

In the event of a breakdown, the BMW Motorrad mobility services available for each new BMW motorcycle enable you to access an extensive range of services such as breakdown assistance, motorcycle transportation etc. (details can differ from country to country). In the event of a breakdown,

contact the Mobile Service organisation of BMW Motorrad. The specialists will provide the necessary advice and assistance. You will find important country-specific contact addresses and the after-sales service organisation phone numbers in the "Service Kontakt / Service Contact" brochures, along with information on Mobile Service and the dealership network.

BMW Motorrad service network

BMW Motorrad has an extensive after-sales service network in place to look after you and your motorcycle in more than 100 countries. In Germany alone, you have the best possible access to approximately 200 authorised BMW Motorrad dealers.

All information concerning the international dealership network can be found in the brochure

"Service Contact Europe" or "Service Contact Africa, America, Asia, Australia, Oceania".

Maintenance work

BMW Pre-delivery Check

Your authorised BMW Motorrad dealer conducts the BMW pre-delivery check before handing over the motorcycle to you.

BMW Running-in Check

The BMW running-in check has to be performed when the motorcycle has covered between 500 km and 1,200 km

BMW Service

The BMW Service is carried out once a year; the extent of servicing can vary, depending on the age of the motorcycle and the distance it has covered. Your authorised BMW Motorrad dealer confirms that the service work has been carried out and enters

the date when the next service will be due.

Riders who cover long distances in a year might have to bring in their motorcycles for service before the next scheduled date. It is to allow for these cases that a maximum odometer reading is entered as well in the confirmation of service. Servicing has to be brought forward if this odometer reading is reached before the next scheduled date for the annual service.

The service-due indicator in the multifunction display reminds you about one month or 1000 km in advance when the time for a service is approaching, on the basis of the programmed values.

Confirmation of maintenance work

BMW Pre-delivery Check

Completed

on _____

Stamp, signature

BMW Running-in Check

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

Confirmation of service

The table is intended as a record of maintenance and repair work, the installation of optional accessories and, if appropriate, special campaign (recall) work.

| Item | Odometer reading | Date |
|------|------------------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

A

Abbreviations and symbols, 6

ABS

- Control, 14
- Engineering details, 84
- Operation, 57
- Self-diagnosis, 73
- Warnings, 31

Anti-theft alarm

- Telltale light, 17
- Warnings, 41

ASC

- Control, 14
- Engineering details, 86
- Operation, 58
- Self-diagnosis, 74
- Switching off, 58
- Switching on, 59
- Warning, 36
- Warnings, 34

B

Battery

- Battery compartment, 128
- Charging battery when connected, 126
- Charging battery when disconnected, 127
- Installation, 128
- Removal, 127
- Stowage, 13
- Technical data, 146
- Warning for battery charge current, 28

Brake fluid

- Checking fluid levels, 105
- Reservoir, front, 13
- Reservoir, rear, 13

Brake pads

- Checking brake-pad thickness, 103
- Running in, 75

Brakes

- Adjusting brake lever, 60
- Checking operation, 102
- Safety instructions, 76
- Technical data, 144

Bulbs

- General instructions, 119
- Overview, headlights, 18
- Replacing front turn indicator bulbs, 123
- Replacing high-beam headlight bulb, 120
- Replacing low-beam headlight bulb, 120
- Replacing parking-light bulb, 121
- Replacing rear light, 124
- Replacing rear turn indicator bulbs, 123
- Technical data, 146
- Warning for bulb failure, 28, 29

C

Case

- Operation, 94

Checklist, 71

- Clock, 20
 - Adjusting, 48
- Clutch
 - Adjusting clutch lever, 60
 - Checking fluid level, 107
 - Checking operation, 106
 - Fluid reservoir, 11
 - Technical data, 141
- Confirmation of maintenance work, 152
- Coolant
 - Temperature gauge, 20
 - Warning, 26
- Currency, 7
- D**
- Damping
 - Adjuster, rear, 11
 - Adjusting, 62
- Dimensions
 - Technical data, 147
- E**
- Electrics
 - Technical data, 145
- Electronic immobiliser EWS
 - Warning, 26
- Emergency off switch (kill switch), 15, 57
- Engine
 - Control, 15
 - Starting, 72
 - Technical data, 139
 - Temperature gauge, 20
 - Warning for engine electronics, 27
- Engine oil
 - Checking level, 101
 - Filler neck, 16
 - Fill-level indicator, 13
 - Technical data, 140
 - Topping up, 102
 - Warning for engine oil level, 31
 - Warning for engine oil pressure, 27
- Equipment, 7
- ESA
 - Control, 14
 - Engineering details, 89
 - Operation, 63
- F**
- Frame
 - Technical data, 147
- Front-wheel stand
 - Installing, 117
- Fuel
 - Filler neck, 13
 - Fill-level indicator, 20
 - Refuelling, 79
 - Technical data, 140
 - Warning for fuel down to reserve, 26
- Fuses, 145
- G**
- Gear indicator, 20
- General views
 - Headlight, 18
 - Instrument cluster, 17
 - Left handlebar fitting, 14
 - Left side of motorcycle, 11
 - Multifunction display, 20
 - Right handlebar fitting, 15
 - Right side of motorcycle, 13
 - Underneath the seat, 16

Grip heating, 59
Control, 15

H

Handlebar fittings
General view, left side, 14
General view, right side, 15

Hazard warning flashers
Control, 14
Operation, 56

Headlight
Adjustment for driving on left/
driving on right, 66
Beam throw, 66
Overview, 18

High-beam headlight
Switching on, 55
Telltale light, 20

Horn, 14

I

Idle
Telltale light, 20

Ignition
Switching off, 46
Switching on, 46

Immobiliser, 47
Warning, 26

Instrument cluster
Ambient-light brightness
sensor, 17
Overview, 17

J

Jump starting, 125

K

Keys, 46

L

Laying up, 134

Lights
Control, 14
Headlight flasher, 14, 55
High-beam headlight, 14
Parking light, 55
Switching on high-beam
headlight, 55
Switching on low-beam
headlight, 55
Switching on the side lights, 55

Luggage
Instructions for loading and
securing objects, 93
Luggage loops, 16, 67

M

Maintenance
General instructions, 100
Maintenance intervals, 151

Mirrors
Adjusting, 61

Mobility services, 150

Motorcycle
Laying up, 134
Parking, 77
Restoring to use, 134

Multifunction display, 17
Overview, 20

O

Odometer and tripmeters, 20
Control, 14
Operation, 49

On-board computer
Ambient temperature, 52
Average consumption, 52

Average speed, 52
Control, 14
Oil level, 53
Operation, 51
Range, 53
Warnings, 29

P

Parking, 77
Parking light, 55
Power socket, 11, 92
Pre-ride check, 73

R

Rear-wheel drive
 Technical data, 142
Rear-wheel stand
 Installing, 118
Refuelling, 79
Reserve volume
 Warning, 26
Residual range, 50
Restoring to use, 134
Rev. counter, 17
Rider's Manual
 Stowage, 16

Running gear
 Technical data, 142
Running in, 74

S

Safety instructions
 Brakes, 76
 General, 70
Seat
 Installation, 67
 Lock, 11
 Removal, 66
Service, 150
Service-due indicator, 21
Shifting gear
 Shift assistant, 75
Side stand
 For starting, 72
Spark plugs, 146
Speedometer, 17
Spring preload
 Adjuster, rear, 11
 Adjusting, 62
Starting, 72

Status indicators
 See also warnings, 20
 Standard status indicators, 20
 Warnings, 23
Steering lock
 Locking, 47

T

Technical data
 Battery, 146
 Brakes, 144
 Bulbs, 146
 Clutch, 141
 Dimensions, 147
 Electrics, 145
 Engine, 139
 Engine oil, 140
 Frame, 147
 Fuel, 140
 Rear-wheel drive, 142
 Running gear, 142
 Spark plugs, 146
 Standards, 7
 Transmission, 141

- Weights, 148
- Wheels and tyres, 144
- Telltale lights, 17
 - Overview, 20
- Toolkit
 - Contents, 100
 - Stowage, 16
- Torques, 137
- Transmission
 - For starting, 72
 - Technical data, 141
- Transportation
 - Lashing, 80
- Troubleshooting chart, 136
- Turn indicators
 - Control, 14
 - Operation, 55
 - Telltale light, 20
- Type plate, 13
- Tyre pressure monitoring RDC
 - Adhesive label for rim, 109
 - Engineering details, 88
 - Operation, 54
 - Warnings, 36

- Tyres
 - Checking inflation pressure, 65
 - Checking tread depth, 107
 - Recommendation, 108
 - Running in, 75
 - Table of tyre pressures, 16
 - Technical data, 144

V

- Vehicle identification number, 13

W

- Warning lights, 17
- Warnings, 23
 - Mode of presentation, 23
 - With ABS, 31
 - With anti-theft alarm, 41
 - With ASC, 34
 - With on-board computer, 29
 - With RDC, 36
- Warnings, overview, 24, 30, 33, 35, 38, 42
- Weights
 - Payload table, 16
 - Technical data, 148

- Wheels
 - Change of size, 108
 - Checking rims, 108
 - Installing front wheel, 111
 - Installing rear wheel, 115
 - Remove the front wheel, 109
 - Removing rear wheel, 113
 - Technical data, 144

Details described or illustrated in this booklet may differ from the motorcycle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be entertained as a result of such discrepancies.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

© 2009 BMW Motorrad

Not to be reproduced either wholly or in part without written permission from BMW Motorrad, After Sales.

Printed in Germany.

The most important data for a filling-station stop can be found in the following chart:


| Fuel | |
|------------------------|---|
| Recommended fuel grade | 98 ROZ/RON, Premium plus unleaded 95 ROZ/RON, Premium unleaded (fuel grade, usable with power- and consumption-related restrictions) |
| Usable fuel capacity | approx. 19 l |
| Reserve fuel | ≥4 l |
| Tyre pressure | |
| Tyre pressure, front | 2.5 bar, Tyre cold |
| Tyre pressure, rear | 2.9 bar, Tyre cold |

BMW recommends 

Order No.: 01 41 7 725 851
05.2009, 2nd edition



K 1300 S, K 1300 R, K 1300 GT



(D)



Möglicher Bremsleistungsverlust an der Vorderradbremse.

Nach allen Arbeiten, die Einfluss auf den Flüssigkeitsstand im vorderen Bremskreislauf haben (z. B. Bremsbeläge erneuern oder Bremsflüssigkeit wechseln), muss der Gittereinsatz **1** im vorderen Ausgleichsbehälter für Bremsflüssigkeit erneuert werden. Wenden Sie sich dazu an eine Fachwerkstatt, am besten an einen BMW Motorrad Partner.

(GB)



Possible loss of stopping power at front brake.

Screen insert **1** in the front brake-fluid reservoir always has to be replaced on completion of work that affects the level of fluid in the front braking circuit (for example replacing brake pads or changing brake fluid). Please contact a specialized workshop for this purpose, preferably an authorized BMW Motorrad retailer.

(USA)

(F)



Perte possible d'efficacité du frein avant. Après des travaux qui influent sur le niveau de liquide de frein dans le circuit de frein avant (p. ex. remplacement des plaquettes ou renouvellement du liquide de frein), il est impératif de remplacer la grille **1** à l'intérieur du réservoir de liquide de frein avant. Adressez-vous pour cela à un atelier spécialisé, de préférence à un concessionnaire BMW Motorrad.

E



Posible pérdida de la capacidad de frenado en el freno de la rueda delantera. Una vez finalizados todos los trabajos que influyen en el nivel de líquido del circuito de freno delantero (p. ej., cambio de las pastillas de freno o del líquido de frenos), se tiene que sustituir la rejilla **1** del depósito de compensación delantero para el líquido de frenos. Para ello, póngase en contacto con un taller especializado, preferentemente un concesionario de motocicletas BMW.

I



Possibile diminuzione dell'effetto frenante del freno della ruota anteriore. Dopo aver eseguito tutti i lavori che comportano delle variazioni nel livello del liquido nel circuito freni anteriore (ad es. sostituzione delle pastiglie o del liquido freni), occorre sostituire l'inserto **1** nel serbatoio di espansione del liquido freni. Rivolgersi a tal fine ad un'officina autorizzata, preferibilmente ad un Concessionario BMW Motorrad.

S



Framhjulsbromsens bromseffekt kan försämrats. Efter alla arbeten som påverkar vätskenivån i den främre bromskretsen (t.ex. byte av bromsbelägg eller hydraulvätska) måste gallerinsats **1** i det främre expansionskärlet för hydraulvätska bytas ut. Kontakta en fackverkstad för detta, företrädesvis en BMW Motorrad-partner.

NL



Mogelijk verlies van remvermogen van de voorrem. Na alle reparaties, die invloed kunnen hebben op het remvloeistofpeil in het voorremcircuit (bijv. remblokken vervangen of remvloeistof verversen), moet het rasterelement **1** in het voorste remvloeistofreservoir worden vervangen. Hiervoor contact opnemen met een specialist, bij voorkeur een BMW Motorrad dealer.



Possível perda de eficácia de travagem no travão dianteiro. Depois de se efectuarem todos os trabalhos que têm influência sobre o nível do líquido no circuito de travão dianteiro (p. ex., substituir pastilhas de travão ou mudar o óleo dos travões), é necessário substituir a grelha **1** no depósito de compensação dianteiro para o óleo dos travões. Para o efeito, dirija-se a uma oficina especializada, de preferência a um concessionário BMW Motorrad.



Etujarrun jarrutusteho saattaa olla heikentynyt. Aina sellaisten töiden jälkeen, joilla on vaikutusta etujarrupiiriin jarrunestemäärään (esimerkiksi jarrupalojen tai jarrunesteen vaihto), täytyy jarrunesteen etumaisen tasaussäiliön ritilä **1** vaihtaa. Käänny tässä asiassa ammattitaitoisen huoltopisteen, mieluiten BMW Motorrad huoltopisteen puoleen.



Πιθανή απώλεια ιζ σύορ θπέων ζ ηρ θπένο μπποαζ ηνού ηησοού. Μερά ηην ππαγμαρποίηζη επααζιών, οι οποίοερ επηηαάζοζ ηη ζ ήάημη ηρς ζγπύ ζ ηρ μπποαζ ηνό κύκλωμα θπέων (π.σ. ανηκαηάζ ηαζ η ηρακιών θπέων ή αλλαγή ζγπύ θπέων), ππέπει να ανηκαηαζ ηαθεί ηρ ζ ηραιοίο πλέγμαηηρ **1** ηρ μπποαζ ηνό δοοοείο ζγπών θπέων. Απερθς ηνθείρε για ηρ ζ κοπό ας ηρ ζ ε ένα εξειδικεζμένο ζς ηεπηγείο ή ακόμη καλύηρεπα ζ ε έναν Επίζ ημο Επίζ κεραζ ηη BMW Motorrad.



フロントブレーキの制動力損失のおそれ。
フロントブレーキに対して、パッド交換やフルード交換など、サーキット内のフルードレベルに影響する作業を行った場合には、必ずフロントブレーキフルードリザーバータンク内のスクリーンインサート 1 を交換してください。交換の詳細については専門の整備工場が、可能な限り BMW Motorrad 正規ディーラーにお問い合わせください。

(SLO)



Možna izguba zavorne moči na zavori za sprednje kolo. Po vseh delih, ki vplivajo na nivo zavorne količine v sprednjem zavornem krogotoku (npr. menjava zavornih ploščic ali menjava zavorne tekočine), je treba zamenjati mrežasti vložek **1** v sprednji izenačevalni posodi za zavorno tekočino. V zvezi s tem se obrnite na specializirano servisno delavnico, najbolje na partnerja BMW Motorrad.

(SK)



Možná strata brzdného výkonu na brzde predného kolesa. Po skončení všetkých prác, ktoré majú vliv na stav kapaliny v predním brzdovém okruhu (např. výměna brzdového obložení nebo brzdové kapaliny), musí být vyměněna mřížková vložka 1 v přední expanzní nádobce brzdové kapaliny. V této souvislosti se obraťte na odbornou díelňu, nejlepšíe na niektorého partnera BMW Motorrad.

(CZ)



Možná ztráta brzdného účinku brzdy předního kola. Po skončení všech prací, které mají vliv na stav kapaliny v předním brzdovém okruhu (např. výměna brzdového obložení nebo brzdové kapaliny), musí být vyměněna mřížková vložka 1 v přední expanzní nádobce brzdové kapaliny. Obratťte se na odborný servis, nejlepšíe na partnera BMW Motorrad.

